Cinmo news issue 6

February/March 1980

CONTENTS

Page	0	This is it.
Page		The bad news !!!!
Page Page	2	The good news (NASPEN Review).
Page		The NASCOM One-Two (?)
Page		Soft Spots.
Page		Documentation Ererrs.
Page	10	S-100 Expansion.
Page		Doctor_Dark's Diary -4.
Page	15	BASIC on One - Shock Story !!
Page	17	Mapping Your Memory.
Page	19	PlOs and Repeat KBDs.
Page	23	Program Hints and Recursion.
Page	25	US (The INMC committee).
Page	2 7	N1 IC18 Problem revisited.
Page	28	Software Library.
_		Nasbug/B-Bug Machine code.
Page		Expand your NI CHEAP !!
Page	32	Software Library.
_		8K BASIC Programs.
Page	33	Free Progs.
_		Pirannha for NAS-SYS.
Page		Program Book.
Page	36	Free Progs.
	•	HANGMAN for 8K BASIC.
Page	38	Lawrence meets the INMC.

INMC Services.

INMC News. This is the main function of the INMC. The newsletter appears every 6-8 weeks, depending on whether you send us articles or not!

Back Issues. Back Issues of the INMC News are available for 70p each + 15p p & p per order. (40p Overseas)

Program Library. Programs sent in by members are vetted by the committee and added to the library list. We admit to being a lot behind on this one !!

Our address is: INMC, c/o Nascom Microcomputers, 92 Broad St., Chesham, Bucks.

PLEASE NOTE: WE ARE NOT NASCOM!! This address is purely a postbox and we cannot arrange to send you leaflets or answer sales queries.



news release

Nascom Microcomputers Ltd. which has become Britain's leading Micro board Company announce a re-organisation within the Company and also, sadly, the resignation of their Marketing Director, Kerr Borland.

The John Marshall - Kerr Borland team started Nascom in January 1978. They have steered it through many birth - pains to reach the dominant market position they have now achieved. This very success has resulted in the split.

Kerr Borland has always said that his interests lay in promoting and creating a sound market base for new products. Once the product was successfully launched, others were better suited to continue. For this reason he is leaving Nascom to set up a new promotions company called Product Launch. This company will cope with all the specialised marketing that is needed in the short term when presenting new products to the market place.

Nascom immediatly become his first customer and he will continue to launch Nascoms new product range due throughout 1980.

In the wake of Kerr Borlands departure, Nascom are reorgansing their Sales and Marketing function. Sales Management will be taken over by another Board member, Bill Bulman, and the company will create a new Marketing section separate from the Sales function.

Nascom has a huge user base throughout Europe and Scandinavia and an extensive distributor network. In two years it has reached a market position that has encouraged many small companies to produce peripherals for use with Nascom equipment.

This firm base which spreads across industrial, educational and home user areas makes an excellent springboard for attacking the 1980's market place.

NASPEN

Word processors !!!! Two words which are becoming as rapidly devalued amongst computing circles as the words 'High Fidelity' are already amongst the audiophiles. Now its not our purpose to bandy definitions, but when definitions become meaningless, then their use ought to be actively discouraged. All this comes to mind, as, at a recent exhibition the words 'Word Processor' seemed to be thrown about with such abandon that any potential customer could only have been confused by the multiplicity (or lack of) specifications which were on display. We saw one beastie which for a modest one hundred and fifty pounds had just about as much in its 4k as half the new Nascom 2K Naspen at about one fifth the price; and they had the cheek to call it a 'Word Processor'!

Which brings us to the subject of Naspen. We have made passing mention of this before, and the results may be seen in parts of this, and the last two newsletters. We have been priviledged to have been loaned preproduction samples to play with, and to say the least we are impressed. And it is not generalized into a 'Word Processor', but is much more specifically a 'Text Editing and Formatting' package and a pretty superior one at that. Now that Naspen is becoming available, it is perhaps time to talk about it a bit, and tell you what it is, and what it does.

Naspen is a program supplied in 2 2708 EPROMs for use with expanded Nascom 1 or 2. There are two versions, VS.1 for Nas-sys monitors and VT.1 for Nasbug T4, it is not suitable for Nasbug T2 and B-Bug. It is really intended for use with 16K of RAM, but at a push 8K can be used, provided the pointer to top of RAM is altered accordingly. Naspen is aimed at people who would want to enter text into their Nascom, and then print it (or just save it on tape for reference). Its main uses would be in the preparation of documents, drafts (including INMC newsletters), repetetive letters, price lists etc. In other words small business applications where editing and correction of printed text would show the benefit of automation.

Because Naspen was designed to be used by inexperienced operators, all the commands are direct acting, and single character only, for instance, in writing a tape, there is no need to tell Naspen where to write from and to, and then enter the line. The W command acts directly, and automatically starts writing to tape two seconds after 'W' has been typed. A major feature is the repeat keyboard which repeats characters at a rate determined by the operator. In the Insert and Append modes the text being written is always displayed, whilst in the edit mode the text may be moved around at will. It is best to imagine the screen as being a window onto the text buffer, and the window is allowed to move over the text buffer. There are no problems with lines longer than 48 characters as the lines simply wrap round the screen (a little disconcerting at first, but after an hour or so, no longer a problem).

The documentation supplied with Naspen is thorough and detailed and again written with the inexperienced operator in mind. We understand that the documentation was tried out on a typist who had never touched a Nascom in her life, and then re-written in the light of her mistakes. We found it accurate if a little clinical in style. The demonstration examples stopped rather abruptly. All the commands were

explained in detail, but it is pity that no abrieviated list of commands was given.

append/insert mode. In all there are 44 commands (43 in the VT version) which are may be considered in six groups.

- A and I are the append and insert modes. Append places text at the end of the text, insert places text within the text. Lower case commands c, d, and i, change, delete and insert single characters in the edit mode. D deletes a line in the edit mode. M is used to move chunks of text around within the text.
- 2) C, G, L, S, s, X, 1, 2, 3 and 4 are all formatting commands. 1, 2, 3 and 4 set up the line and page lengths. L left justifies the text to width, whilst S and s left/right justify the text to width, inserting extra spaces as required. G generates pages to length, whilst C and X remove the affects of formatting.
- Finding bits of text is important, and the F, f and a commands will find strings of up to 40 characters within the text.
- 4) Commands for entering and saving text to tape are covered by the R, W and V (VS version only) commands. There is also a special tape command, the J command, which will insert an incoming tape in front of text already the Naspen.
- Moving the cursor about within the text is perhaps the most important facility of any text editor, and Naspen has no less than 14 cursor move commands. The text and cursor may be set back to the start, the cursor may skip backwards and forwards in pages, lines, tens of characters or singly. Making it very easy to position the cursor anywhere in the text.
- The last group are all unrelated. The K command will kill text and because of its irreversible action is protected against accidental use by the Y command. N returns Naspen to the monitor, whilst P prints the text. Commands 5 and 6 set the repetition rate of the repeat keyboard.

In use we found Naspen very easy to get on with, and in preparing INMC pages it is wonderful, as none of us qualify as typists, the ability to skip through what we have done, then correct it with out having to retype the lot has saved an enormous ammount of time. As mentioned elsewhere, we shunt 'Pen' tapes about, edit them and finally print them on an old IBM printer. Incidentally, you may have noticed we have avoided the 'pound sign' in this text. Not because 'Pen' can't use it, but because the IBM golfball doesn't have one.

In all Naspen seems a very versatile and worthwhile addition to the Nascom stable for those who want a reliable text editor. We have found that it covers all normal (sic) facilities in a very easy to use package. It takes about three hours to get conversant with it. And as a final recommendation, takes a look at these two pages. It's a real pity it doesn't find the spelling mistakes as well!! That would be really something to shout about.

N1~2

THE STORY OF THE NASCOM ONE-TWO

Or Why Two Computers are Better than One

by Richard Beal

Is the Nascom One-Two a marvellous product of the distant future? No, it is already here, and consists of a Nascom 1 connected to a Nascom 2 to form a new and versatile computer system with the following features:

- (a) Ability to read data from Nascom 1 tapes directly into a Nascom 2. This works even with an unexpanded system.
- (b) Intelligent giant print buffer for serial printers such as the Nascom Imp or Teletype. This enables output from ZEAP, BASIC or NASPEN to be routed to the Nascom 1 memory virtually without delay, and with automatic compression of blanks, to save valuable RAM space. Printing is completely independent of the Nascom 2, and can proceed at the same time as more data is being sent across at high speed. If the print buffer becomes full, the Nascom 2 will automatically wait until printing starts, or if required the print buffer can be cleared if the output is not, after all, needed. Printing can be paused at any time, and the Nascom 1 display shows the number of characters waiting to be printed.
- (c) Almost instantaneous transfer of the whole of the contents of memory from one machine to the other, allowing very fast recovery of programs and data when testing machine code programs. For example ZEAP could be used on the Nascom 2, and the source code and generated machine code both held in memory. Then before testing the program, which could well crash and change the contents of any part of the memory, the whole memory is copied in a few seconds to the Nascom 1. When the Nascom 2 crashes, it is simply reset, and the data brought back. Within seconds the ZEAP source can be edited and re-assembled and the process repeated.

These facilities are very useful, and mean that if you have bought a Nascom 2, your Nascom 1 can continue to be used instead of putting it in the attic, or trying to sell it, which is rather sad after all the effort needed to build it. It also gives you another reason for buying a Nascom 2 if you already have a Nascom 1!

At this point you may be wondering what sort of equipment you need for all this. If you have a Nascom 1 and Nascom 2, all you need is NOTHING!!!

Obviously if the Nascom 1 is not expanded, only feature (a) is possible. The only hardware work required is to connect various lines from the Nascom 2 26 way ribbon cable to the Nascom 1 PIO sockets. Only one port on each machine is used, with all data transfer being interrupt driven using the handshake lines. To understand this, read the PIO technical manual until you are sure you know it all. (I have read it about 30 times and am still not completely confident). Alternatively, read on.

Connect the 8 data lines of port B on the Nascom 2 to the coresponding 8 data lines of port B on the Nascom 1. Connect the ground line of the N2 to pin 9 (ground) of the N1. Connect the B READY line from the N2 to the B STRB on the N1 and the B READY line on the N1 to the B STRB line on the N2. Do not connect the power lines together! You may choose to wire a switch so you can see the N1 or N2 display on the monitor screen, but you don't really need the N1 display. If you wire such a switch, wire the earth lines together.

One further point on hardware is that for some strange reason the memory board links togther the IEI and IEO. This doesn't matter on the N1, but the N2 brings these lines out correctly to NASBUS, and the PIO won't interrupt unless IEI is high. Simply look at the edge of the memory board, next to line 19, and you will see that it is connected to the next line. Break this join by scraping away with a screwdriver. (Ed. Don't do that, the memory board is correct, it is the mini Vero bus on the N2 which is wrong. Break track 19 on the Vero board. See note under the article about PIOs.)

As you will have realised, the key to the Nascom One-Two is in the software. We will just cover feature (a) the cassette input via Nascom 1. This is extremely useful for converting your tapes from N1 to N2 format.

Since giving you the program listings would make it much too easy, here is a description of the little programs which you need to put into each computer. (The listings will be put in the library in due course.)

Cassete input transfer program for Nascom 1

This program initializes the PIO and then goes into a loop which does nothing at all. However, each time there is an interrupt the interrupt routine waits until there is a character from the cassette input, and then outputs it to the PIO and returns. The full list of actions is:

Disable the CPU interrupts with a DI instruction.

Disable PIO (03H to control port).

Ensure PIO is happy by pushing address of next instruction on to the stack, and then using a RETI.

Load I register.

Set interrupt mode 2, with IM2.

Output the interrupt vector (low order half address of the interrupt address table).

Output OFH to PIO to set it to output mode.

Set the interrupt control word by outputting 87H to the PIO.

Enable the CPU interrupts with an El instruction.

Go into a tight loop (actual code 18 FEH).

That is the end of the initialization program, which is executed.

Then you need an interrupt address table. The high order part of the address of this table has been stored in the I register, and the low order part has been sent to the PIO as the interrupt vector (this must be an 'even' number, ie. last bit = 0). The interrupt address table actually contains just one address, which is the address of the

interrupt routine itself. This address is placed at the start of the table, low order byte first, as usual.

The interrupt routine itself calls its own copy of the SRLIN routine and loops until the routine returns with the Carry set. It then outputs the character to the PIO, enables the CPU interrupts and immediately returns. This last bit of code reads:

OUT (5), A EI RETI

Cassette input program for Nascom 2

The other half of the software lives in the Nascom 2. The program initializes the PIO just like the other program, except that the PIO mode is 4FH, for input mode. After setting up the PIO, the CPU interrupts are not enabled. Instead a dummy READ to the PIO is made to ensure that handshaking starts. Then a version of the READ routine, copied out of NAS-SYS, is executed. If the routine ends, control returns to NAS-SYS. Instead of the need for changing tables and RST RIN to get an input, normal calls are made to a new routine called CIN. This routine reads as follows:

CIN OR A
EI
SLP JR NC SLP
RET

This loops until an interrupt occurs, and the interrupt routine sets the Carry flag, and puts the input character into A. The interrupt routine reads simply:

PROC IN A, (5) SCF RETI

Note that it does not re-enable CPU interrupts.

As you can see, the use of the PIO requires a bit of thought, but if you read the notes above, and have a look at the PIO manual, you should be able to write these routines for yourself, exactly as you wish, which is much more interesting than typing in some HEX listings from the library.

Please write in and let others know if you have any other uses for two (or more) machine systems. How about a controlling machine loading other slave machines with data, programs, perhaps even interpreters as well, then doing other work while the slave machine performs the subordinate tasks. This would be one way to tackle a multi-user operating system with resources such as printer or disc attached to only some machines.

Richard Beal

PS You could use two Nascom 2 computers, if you don't already have a Nascom 1.

PPS Don't blame me if you get your wires mixed up and blow up both computers.

SOFT SPOTS

By Richard Beal (and others)

This tip presupposes that you are a person who assembles machine code in HEX, in memory, and then wants to convert it to DATA statements for use as machine code subroutines with the 8K BASIC. Assuming Nas-sys is in use, try this:

Assemble the machine code routines, in HEX, at the correct location in memory (and perhaps try them if possible). Go into BASIC (making sure that the free memory space does not overwrite the machine code routines). Then use the following command:

WIDTH 40:FOR A = B TO C STEP 2:PRINT DEEK(A);:NEXT Where B is the start address in decimal, and C is the end address. The BASIC will print a series of numbers, stopping well short of the right hand edge of the screen. Using the Nas-sys edit commands, edit in line numbers and commas, and the job is done. No mistakes through trying to calculate the decimal equivalents of the HEX, or through copying the numbers wrong. What's more the data is in double byte form, which may be loaded down using DOKE commands, taking half the time that it would take to POKE the data down.

Suppose you want to test to see if one of the 16 bit registers HL, DE or BC is zero. For example, this could be at the end of a loop that was counting down. A version of this in a magazine had the following:

DEC DE

LD A, D

OR A

JR NZ LOOP

LD A, E

OR A

JR NZ LOOP

It would be a lot easier to put:

DEC DE

LD A, D

OR E

JR NZ LOOP

Suppose you want to jump to a certain address in your program, and that this address is currently stored in the HL register. You can just code:

JP (HL)

This works very well.

Now suppose that you need to have set HL to a certain value when the jump is made. The method above is useless because HL can't be at two different values at once. So code:

LD HL, value of HL

PUSH HL

. LD HL, address to jump to EX (SP), HL RET

or:

LD HL, address to jump to PUSH HL LD HL, value of HL RFT

The second method is the simplest, but often the value of HL is already on the stack, making the first method the most commonly used.

Now suppose that you in fact wanted to call the routine, not to jump to it as above. In this case the return address can be pushed onto the stack in advance. For example:

LD HL, value of HL PUSH HL

LD HL, return address
EX (SP), HL
PUSH HL
LD HL, address of routine
EX (SP), HL
RET

This will call the routine and then return to the specified address. The original value of HL has been preserved and passed to the routine.

If the subroutine decides to, it can change its own return address, again using:

EX (SP), HL

However, this is bad programming practice because it destroys the structure of CALLs.

It is bad practice to set the stack pointer except at the start of the program where it can be useful for re-initialisation. It is very bad practice to ever use the instruction DEC SP because this implies that you have data stored on the stack at an address less than the current stack pointer (I've used DEC SP to 'throw away' unnecessary data on the stack, I don't see anything wrong with that; Ed.). NAS-SYS I used this instruction, and is, I'm afraid, noninterruptable. By noninterruptable I mean that an interrupt at the wrong moment will crash the program. In fact close examination of the NASBUG monitors shows that the storing and restoration of registers is noninterruptable so they are no better. Will something be done to correct this small defect? Maybe!!

Do you know the correct name for a 'crash', meaning the loss of control by a program resulting in unpredictable changes to memory locations and usually requiring the reset button to be pressed? The correct name for a 'crash' caused by bad code is a 'program fault'. It sounds more impressive but it is just as annoying!

ZEAP in EPROM

A number of people have sent in details of how to put ZEAP into EPROMs and copy it down to its correct location. Others have worked out how to put extra features into ZEAP, such as paginated output.

N2 Documentation Errata

Nascom Engineering have forwarded a list of errata for the Nascom 2 manual which they have asked us to publish: so here goes.

"Nascom 2 construction manual

page 5 para 7 The diagram 'component representation' shows the +

the wrong end of the diode symbol. TR1 and TR2 are PNP and not NPN; TR4 is shown inverted in the fourth column of diagrams. page 6 para 8

page 10 para B4 IC9 should be N2DB PROM; IC17 should be IC16

para C1 IC25 should be '81LS97 or 95/97'

para B5 delete 'causes'; insert 'may cause'.
page 11 para H1 TP4 and TP5 are inactive at this stage, though stated signals are available from them during normal operation.

"Nascom 2 circuit diagram

The drawing number, 4-022-103, is to be deleted and replaced 1) with 022-401 (sheet 1 of 5), 022-402 (sheet 2 of 5), 022-403 (sheet 4 of 5), 022-404 (sheet 4 of 5), and 022-405 (sheet 5 of 5)."

(Editors note: we think they mean 'sheet 3 of 5' for drawing 022-403; they didn't tell us where you get the drawings from.)

- "2) (022-401) TR1 should be shown as a PNP common collector stage with R14 connected to the emitter and collector grounded.
- 3) (022-402)TR2 should be shown as a PNP common emitter stage, with connected to the collector and the connected to +12 volts.
- The capacitor C25 on pin 5 of the UHF modulator should 4) (022-404)be marked DC53. Pin 15 of IC65 is connected to pin 2) of IC65 and not

Pin 10 of IC65 is connected to pin 11) as shown. Ed. 5) (022-401)109/12 is connected to 105/11 and 109/11 is connected to 105/9."

"Nascom 2 Hardware manual

page 15 1st item in the test point list should read 'TP1: 300Hz from 1031/3'.

page 20, note 5 Switch positions are reversed.

page 20 C3 Is as stated and not a tantelum capacitor as mentioned in the construction notes.

> is as listed and not a ceramic as stated elsewhere. C14

C19 Is a tantelum capacitor though this is not mentioned.

C29 ditto

DC45 & DC52 are as stated and not tantelum capacitors as elsewhere.

should be marked 74LS257 and not 74LS32. page 31

page 35 Is shown as a 74LS163, should be 74LS123.

Difficulty has been reported in identification of Note: capacitors. Though it is not possible to guarantee that all manufacturers follow this convention, it is suggested that capacitors marked 102 be regarded as 1n and those marked 100 as 100p unless there are obvious signs to the contrary (size, or the possession of a positive lead).

Nascom 2 RAM board construction notes

- page 5 It is reported that certain boards harbour an etching fault whereby the decoupling capacitor for IC8 fails to connect with the ground rail. It is reasonable to check for this fault and to correct it if possible, although its consequences are unlikely to be noticeable and are nothing to do with 'memory plague'.
- page 12 et seq The memory test programs are written for the T2 monitor and will not operate under Nas-sys 1. It is recommended that the advice given on page 15 is followed and that a small test program is written to test for 'plague' only if this condition is suspected. The printed test programs are not specifically designed to reveal plague." (And probably won't. Ed.)

(Editors note: We do not like these unspecified references to 'memory plague' as unsuspecting purchasers of Nascom 2s would have no idea what is meant; only hardened Nascom 1 owners who read these newsletters will be in the know. For new Nascom 2 owners, 'memory plague' is a condition which arises in some memories due to noise and speed problems, and leads to unreliable memory performance (not to be confused with suspect chips). Several notes have been published about 'memory plague', and we hope to collect them all together and publish a compendium of memory mods in the next issue. Memory plague may be detected in a Nascom 2 by the failure of the Basic to initialize properly, or the 'free memory' message giving silly or inconsistent answers after initialization. This not the same as the total failure of the Basic to initialize if the memory construction notes are followed to the letter (having missed the small errata); where the constructor is instructed to connect decode pad 12 to P5, thus enabling the RAM board EPROM block to page F, thereby totally disabling half of the Basic.)

"8K Basic programming manual

page 16 The list of reserved words should include DEEK and MONITOR.

page 24 The second sentence should read: 'It uses locations 1000H to 113EH (4414) 'The second sentence should read: 'Locations 113FH to DFFFH are therefore'"

(Editors note: Well thats what it said, and we couldn't understand it either, so we looked it up in a manual that was a couple of months old. That didn't make sense either, suggesting that the Basic used 8K+ of workspace, so after a little investigation we think page 24 should read as follows:

"Nascom Basic leaves locations between 0C80H (3200 decimal) and 0FFFH (4095 decimal) inclusive for use by user machine code routines. It uses locations 1000H (4096) to 10F9H (4345) inclusive for workspace and resides in E000H (-8192) to FFFFH (-1) inclusive. Locations 10FAH (4346) to DFFFH (-8193) inclusive are therfore available for the users' Basic program and data.")

"page 26 program 1 line 40: the word 'to' should be in upper case."

For a manual the size of the Nascom 2 manual you must expect a few mistakes but we bet they haven't all been found (we haven't tried looking yet), but if you come across any please let us know so that they can be ammended in later manuals. That way new users of Nascom 2 might not run into some of the problems that have been experienced.

S~100

S-100 EXPANSION for NASCOM 1

This is a shortened version of an article sent in by Mr. K. P. Curtis of New Barnet. The INMC would very much like to hear from anyone else who has expanded their Nascom via the \$100 bus.

I decided to expand my Nascom 1 with a \$100 expansion kit currently being offered. Despite being more expensive in the short term, I felt that it widened the choice available to further enhance my system.

The kit consisted of :-

- 1) A double sided PCB without plated through holes that will accommodate three cards.
- 2) Two edge connectors and ribbon cable to connect the Nascom to the expansion board.
- 3) All required IC's and sockets except one, a tri-state buffer for control signals which is optional. (Would recommend this is used ED.)
- 4) Lots of vero pins to make the through board connections.
- 5) Decoupling capacitors.
- 6) A 2K Basic interpreter (B-Basic).

Assembly

The instruction for assembling the board are adequate but the following points should be noted:

Insert all vero pins before soldering and very carefully check their positions as it is very easy to get them in the wrong positions.

Some pins need to be cut short to allow sockets to sit flush on the hoard

The longest part of assembly was making up the ribbon cable assembly - very tedious.

Documentation

A circuit diagram of the logic is provided but does not match the board layout and the logic that generates the MEMEXT signal, although functionally the same, is misleading. Also only the pin numbers of the buffers are given and some of the IC legends appear to have been incorrectly printed on the board.

Beside these errors I found two connections not made in the external I/O logic: IC5/15 to IC10/1 and IC9/11 to IC9/10.

Power Supply

The ready built 8K RAM card that is being used requires an 8V unregulated supply from the S100 bus. This may be obtained from the existing power supply - after the rectifier but before the dropper resistors and regulator. Before attempting to use the kit and memory though, the rating of the rectifier should be checked - mine lasted for

all of five minutes. I now have an 8 AMP bridge which, although bigger, can be easily fitted with the aid of a piece of aluminium which also serves as a heat sink.

Since the RAM board draws about one and a half amps a healthy earth is required - a thick piece of wire from the power supply to the expansion board. However, this creates an earth loop, which perhaps is not desirable. (Suggest that all earths then taken from expansion board Ed.)

Getting It Working

With the kit now assembled and 8K of RAM plugged in that should have been the end of the story, but there were the inevitable problems. The memory could be read from and written to but very machine would lock up. On power-up everything looked fine but the system would not initialise properly on pressing the reset key. Many hours were spent looking for non-existant faults. Eventually it became apparent that the MEMEXT signal was at fault but not why. internal memory select used there was no problem. With external memory select used the problem reappeared, but on monitoring MEMEXT with an AVO it disappeared again. In an attempt to cure the fault the chips at each end of the MEMEXT signal were changed but to no avail. Since the AVO cured the problem a resistor was soldered between the signal line and earth, this made a minor improvement. Next a capacitor was between the signal and earth at the NASCOM 1 end, this fixed it. Decoupling the expansion board end had no effect.

Conclusion ======

This board is not easy to build and may require a small decoupling capacitor to be added to the main N1 board on the MEMEXT line. Having this signal so close to the earth and the +5v lines would appear not to be a good idea. A criticism of the design is that tri-state buffers are used unnecessarily on the control and address lines, surely ordinary buffers would have done the job. Since getting this expansion working I have experienced no other problems and am very happy with it.

Mr. Curtiss neglected to mention the manufacturers of this product, but we believe it is the one supplied by Comp Components of Barnet.

There were a couple of other points in the letter attached to Mr. Curtiss' article which ought to be mentioned. One of the reasons he gave for choosing the S-100 mother board was that it allowed greater choice of 'goodies' that may be fitted. Whilst generally true, this particular board is not truly S-100 compatible, and may give rise to problems under special circumstances. Another reason was that in his opinion the Nas-bus was responsible for some of the trouble experienced with Nascom expansion. In our opinion the trouble is not concerned with the Nas-bus but with the series 1 memory card. Happily these troubles can all be cured. Finally Mr. Curtiss asks why a non ASCII keyboard was chosen for Nascom and says, "Surely it would only cost a few pounds

DOCTOR DARK'S DIARY-4

(An every day story of simple programming folk)

Issue five of the INMC News arrived at Zilog Villas just in time for Christmas - this was clearly the result of a prodigious effort by both the committee and the post office. Having suggested to our illustrious editor that he should print both the episodes I had sent in at once if there was a shortage of material, I was caught with my pencil down. The pressure is on now, no more playing with the piranhas until I have typed this episode out.

MAKING M5 RUN BIGGER PROGRAMS

If you have run Microdigital's M5 interpreter, you will know that it can only run programs of about 230 bytes or less, depending on how much use is made of the stack. On an expanded Nascom, only a few changes need to be made to the M5 interpreter to move the program store to the additional memory. The changes are as follows:

ODE1 00 10 0E06 FO : OE 0E2F \mathbf{FF} \mathbf{OF} OF OE5A : $\mathbf{F}\mathbf{F}$ OEB3 00 10 OEDB \mathbf{FF} 0F

As well as changing the program store location, I have also changed the variable stores from the top line of the screen, which was rather unsightly, and put them where the program used to be. There is still plenty of space for the stack to work in, it would take about a hundred consecutive pushes to cause problems — if your calculation is that complex, you should be using Fortran! Should you happen to write a program in M5 that uses 32K of RAM, you may find jumps from the low end of memory to the high end are fairly slow. Serve you right for writing such long programs.

TINY DISASSEMBLER

When I first used M5, I wanted to find out how it worked, so I decided I would disassemble it. Hand disassembly is incredibly tedious, and Personal Computer World still have not printed the end of Parkinson's Revas (a Nascom disassembler, which it just happens you can buy if you have the money). Half way between the two alternatives is a program written by R. M. Lucas, and published in Computing Today, October 1979. This program is called Intab (short for Intelligent Tabulate) and breaks a program up into its separate instructions - much easier to understand than a rectangular block of code. As Intab is probably protected by all sorts of copyright laws, I have taken the diabolical liberty of writing an improved version, which is fully relocatable, and (sorry!) only works with T4.

CDED0E OC 3E 00 \mathbf{CF} FE 5B FE 2E 20 01 20 20 F4 05 00 EF 1F 00 01 $\mathbf{E}\mathbf{B}$ CD32 02 EB 3E EF 20 00 1A FE EF 20 OA **D7** 68 A7 28 2B**F7** 13 1A 18 \mathbf{FE} DDF828 28 FE FD28 24 FEED 28 0E1A 2A 42 3B ocD5 11 9B 00 19 D1ED В1 06 03 28 0B01 19 00 ED **B1** 06 02 28 02 06 01 **D7** 38 18 2A**D5** AA **D**7 32 3B 0C11 **B2** D1 00 19 ED B1 28 \mathbf{DE} 0C **D**5 11 **D4** 2A3B 00 19 **D1** ED OE OB В1 28 DC06 18 DA **D7** 10 0C2A023B 0C**D5** 11 CE00 19 D1 ED 18 С6 **B1** 28 BB06 01 CD44 02 02 CD3C 13 1A 10 Fб C9 01 11 31 32 3A C2C3 C4 CC D2CA CDD4EA F4 DA DC E2 **E4** EC F2FA FC21 22 2**A** 36 CB06 16 1E 26 28 0E10 18 20 2E 30 38 3E С6 CED3 D6 DB \mathbf{DE} **E**6 EE **F**6 \mathbf{FE} 43 **4B** 53 5B 73 **7**B 09 19 23 29 2B**E**5 (Phew!) 39 E1 E3 E9 F9

How to use it

- Load the above into a section of RAM not used by the program you
 Load the program you want to dissect.

 wish to examine.
- 3. Use the command E xxxx yyyy $_{NL}$, where xxxx is the address of the first byte of the above, and yyyy is the address at which disassembly is to start.
- 4. Press the space bar to produce each line of code in turn, and full stop to return to the monitor.

The program does not understand about data tables, and the fact that RST 16 (D7) is followed by a displacement when using T4.

WHAT HAVE I DONE WITH IT SO FAR?

Having found out how M5 functions, I decided to write a Pilot interpreter, as threatened in episode 3. In a trice (about three weeks) it was finished. It didn't work. Not only that, it was so complex, and my documentation so poor, that I could easily have spent another three weeks trying to find the errors.

- MORALS a) Test each section as it is written
 - b) Make detailed notes, you will forget how it works, and nobody else knows!

In a flash (another ten days) I took the easy way out, and re-wrote the whole thing, testing each section as it was completed. When it was finished, it worked first time, some of the time. The dreaded memory plague had struck - fortunately, it was in its mildest form, and was easily dispelled with a National chip in the recommended place. This is interesting, as the memory test programs supplied with the board did not reveal any problems, obviously there is an application for the interpreter as a test program here....

Anyway, I now have a 2K Pilot interpreter running, and have even written a few programs in Pilot, the easiest language I have ever seen. I'm now half way through version 3, and it looks even better. I will keep you informed of its progress.

Doctor Dark and Marvin wish a happy and prosperous 1980 to all intelligent life-forms in the Galaxy (and to the rest of you, the secret is to bang the rocks together....)

SHOCK HEADLINE

AUTHOR FINDS OWN BOOBS IN INMC ARTICLE

by Ms D. R. Hunt

No, not a refugee from page 3 (we got told off by readers last time we let a naughty word onto these hallowed pages), but to draw your attention to the fact that we all make mistakes. Last issue, we published a bit about adapting the series 1 memory card to carry the 8K Basic ROM, and went on to describe how to put the remaining three EPROM sockets back into use. Well the Basic ROM bit works, but the EPROM bit doesn't!!!

Having fitted the Basic ROM to the card, and written it up for the INMC, in a most un-natural fit of enthusiasm, I modified the board for the EPROMS, 'zapped' in a couple of EPROMS, gave it a quick go and wrote it up, but because of the closeness of the copy date, I didn't get round to actually testing it thoroughly. Later, (over Christmas), horror of horrors, fit some EPROMS and the Basic does funny things. Close examination of the circuit reveals that enable of IC24 (pin 1) comes on when the Basic ROM comes on, so with EPROMS fitted they are enabled along with the Basic ROM resulting in rubbish on the bus. The strange thing is though, that in the conflict between the EPROMs and the ROM, the ROM usually won, so Basic didn't just crash as you'd expect, but became unreliable.


At first sight this problem looks very difficult, requiring a three pole switch (very hard to find) to switch the IC24 enable along with the Basic enable, and the decodes. However, look at the circuit again, it won't take long to realize that the enable line to IC26 (which we already use for the Basic ROM) could just as well be used to enable IC24 instead of the signal currently used.

So, now to the correct version, refer back to the previous article, and notice that a 4K7 pull up resistor (on the right hand connector) is used to disable the Basic ROM when not in use, leave this where it is, but reverse the connections to the other side of the switch. Viz: IC26 pin 19 is connected to the pole of the switch, and IC27 pin 20 is connected to the left hand connector. Further, another 4K7 pull up resistor has to be fitted to IC27 pin 20 to pull the Basic ROM 'off' when the switch is over the other way. Carefully cut the track to IC24 pin 1 (adjacent to the pin), and connect pin 1 to the right hand connector of the switch, leaving the existing 4K7 pull up resistor in place to turn IC24 'off' when the switch is over to the Basic.

All this seems to work satifactorily, but we have heard of a few cases of difficulty (even without EPROMs on board), a 'Stop Press' was added to the previous article about fitting a 100n capacitor across the back of the ROM to decouple the supply lines, I have found that 2u2 bead tant. is better. You wouldn't believe the 'crud' the Basic ROM generates on the supply line as it's enabled, if you've got a 50MHz scope to hand, have a look at it across pins 12 and 24. A further aid to quieting down and speeding up the system is to decouple each EPROM socket with 10n, and to pull the data outputs of the ROM and EPROM block high with 10K resistors.

We've mentioned memory plague before, and a recent note in the INMC newsletter gives a more consistent cure. However, whilst looking for the troubles with the Basic ROM with EPROMs in situ, a remarkably naughty bit of tracking on the earth line of the EPROM block was discovered. The earth track is connected to the ground plane close to pin 12 of IC27, but nowhere else!!! So! now suggest when gridding the back of the pcb that pin 12 of ICs 28, 29 and 30 be incorporated in the grid thereby incorporating the EPROM sockets firmly into the ground plane. It can't do any harm, and seems to do some good (but difficult to prove).

By this time the back of the memory board is beginning to look like the classic 'rats nest' with bits of wire and resistors hooked all over it. Don't worry, finding the cures, and incorporating the mods was fun wasn't it? And after all, the thing works reliably (or should anyway).



Memory maps

Software of the future

What is the perfect memory layout for the future? What software should be resident in ROM and what should be loaded from tape? You might like to think about these questions in regard to some of the software that already exists or is rumoured to be around.

Nas-sys 1 This must be in ROM, and naturally lives at 0000H, although it is not totally impossible to put it elsewhere with Nascom 2.

Basic Both Rom and tape versions exist. Nascom 2 has it at E000 - FFFFH.

ZEAP This assembler is a candidate for ROM as it is so useful. ZEAP 2.0 can be in ROM at D000H or RAM at 1000H.

REVAS This disassembler can be located anywhere. Is it used often enough to make it worth having in ROM? It could occupy C400 - CFFFH

All this brings us to memory mapping. So much is going on by independent people, hoping to sell products under the Nascom banner, that a meeting was held recently between Nascom Engineering, and other interested parties. The aim; to ensure that there is room for everything, and that everything can be kept under control. The meeting primarily discussed a standard Nascom 2 expanded to a maximum of 48K and fitted with Nas-sys. Non standard Nascoms and disc based Nascoms were not discussed as their memory requirements will be entirely different. But everything decided is equally relevant to an expanded Nascom 1 fitted with Nas-sys.

One of the mains aims was agreed, and that is that no external product can advertise that it is 'approved by Nascom' unless it has been submitted to Nascom for approval, and that it conforms to the memory mapping laid down. Another aim was to produce a reccommended memory map for use with Nascom 2, but is was soon discovered that so many diverse ideas were around that it was only possible to set out guidelines, and that firmware producers would have to look at their product to see where it could be sensibly fitted. This is in the producer's interest, because if something is located in a daft place then it inhibits its own market.

FFFF E000	8K Basic	
DFFF D000 ====	ZEAP 2.0	or general assembler type software or extensions to Basic.
CFFF C000 ====	REVAS	or general disassembler software or Colour graphics control software.
BFFF B800	Naspen	or related word processing software.

```
Extensions to the operating system
B7FF
B000
                         or extensions to Naspen.
===
AFFF
        Colour graphics RAM or general RAM space.
9800
97FF
        Programmable grahics RAM or general RAM space.
9000
8FFF
        General RAM space.
1000
        Start of general program space.
====
OFFF
        Usual stack space.
0F80
====
0F7F
        Workspace for firmware
0D00
                or workspace for programs.
====
0CFF
        Extended operating system workspace.
0080
====
0C7F
        Existing operating system workspace.
0000
OBFF
        Existing video RAM.
0800
====
07FF
        Existing operating system.
0000
```

As you will notice, firmware which is unlikely to be used been assigned coresidence. For example, no-one is likely together has to want to use the colour graphics firmware (which runs under Basic) REVAS (which is a machine code disassembler). Similarly, any with extensions to Naspen may be made from B000 -B7FF, with a more as powerful word processor in residence, extensions to the operating system would hardly be required, and so on. However, extensions to the could imply the use of a more powerful operating system, or a software number cruncher such as MAPP1-3Z could be put in place of ZEAP, and used to extend the precision of the Basic math to 14 digits (if any one has done this please let us know).

So please bear these suggestions in mind in writing your software, that way maximum portability, and least inconvenience is caused.

S-100 (continued from page 12)

more for a real one". Well we don't know, but in general the Nascom keyboard costs rather more (not less) than the average ASCII keyboard fitted to competing computers, and is a very rugged and superior product. We don't know why all the control is done in software, as it would have cost little more to make the keyboard truly ASCII. Mind you, a software controlled keyboard lets you do lots of clever things which a hardware keyboard could never do (look at the N Ray Moonlander program for instance). Finally, does it really matter, as ASCII keyboards can easily be run into PORT 0 with very little modification to the software if required.

PIOs & RRRepeat KBDs

A few newsletters back we did an article about the PIO (MK3881), and tried to get readers out of the 'Catch 22' situation, where the PIO technical manual could only be understood if the reader knew something about PIO's. The article dealt with the general aspects of the PIO, and how to use it. Well Richard has been busy, and has sent us this:

Understanding the PIO

The PIO manual provides a good description of how this powerful device works, but there are some aspects of it which are not easy to understand. Perhaps the most confusing of all is the use of the 'handshake' signals, known as STROBE and READY lines. This article will briefly explain how input and output modes work, and then will give an example showing how two PIO's can communicate, when one is the output and the other is the input.

!nput mode =======

The PIO port must be set to mode 1 and interrupts enabled. As usual the I register, interrupt vector and interrupt mode must be set up correctly, and the PIO must not think that it is already processing an interrupt, so a dummy RETI instruction should be executed. Also, when in input mode, a dummy read should be issued once at the start to initialize handshaking. At last you are ready to enable the CPU interrupts with an EI instruction.

The sequence of events is as follows:

The input STROBE line goes from low to high, indicating that data is ready in the PIO input register. This change causes an interrupt, and the interrupt routine gets the data with an IN instruction. Issuing this instruction gets the data and also causes the PIO READY output line to go from low to high, indicating that the data has been received. The interrupt routine ends by enabling the CPU interrupts again and then immediately returns with a RETI, which re-enables the PIO interrupts.

Output mode

The PIO port must be prepared as for input mode, except that it is set to mode 0.

The sequence of events is as follows:

The input STROBE line goes from low to high, indicating that the previous output has been received. This change causes an interrupt, and the interrupt routine outputs the data with an OUT instruction. Issuing this instruction not only outputs the data to the PIO, but also causes the PIO READY line to go high, indicating that data is ready in the PIO. The interrupt

routine ends by enabling the CPU interrupts again and then immediately returns with a RETI, which re-enables the PIO interrupts.

You may have wondered when the READY line goes low. In both modes the READY line goes low when an interrupt is generated. This may be used by the external device to acknowledge that an interrupt has been received. It could be used to inhibit further interrupts from the external device, particularly where a number of PIO's are 'daisy chained' together, and higher priority interrupts are already being processed, hence there will be a delay before the external device is processed. In other words, it says to the external device "OK, seen you, you are in the queue, don't bother me again until I go high.". It has no internal affect on the PIO, save to get it ready to go high again when processing of the interrupt is complete.

Example of handshaking sequence

For two PIO's to handshake, the STROBE (input) line of each is connected to the READY (output) line of the other. This diagram shows a typical sequence of events, starting with a dummy read from the input port to start the process.

Output port Input port ======== ======== IN issued once after PIO initialized.rREADY goes high. CPU interrupts enabled with El. The incoming STROBE goes high, So there is an interrupt. READY goes low. Interrupt routine issues an OUT, and the READY goes high. Interrupt routine ends with EI, RETI, so it is ready for the next interrupt. Incoming (STROBE goes high, so there is an interrupt. READY goes low. Interrupt routine issues an IN, and the READY goes high. Interrupt routine ends with El, RETI, so it is ready for the next interrupt. The incoming STROBE goes high, So there is an interrupt, READY goes low. Interrupt routine issues an OUT and the READY goes high

And so on....

And so on....

You could try this with just one PIO, by making the two ports of your PIO talk to each other.

A note for Nascom 2 owners. The memory card joins the 'daisy chain' (IEI and IEO) lines together, and under these conditions the interrupts won't work. Cut one of the tracks on the vero buss connector. Do not cut the link on the memory board, as this would be required if that card were used on a bigger buss with 'daisy chain' priority interrupts.

Its beginning to look as if this newsletter was written by Richard, because this screed also came from Beal mansions.

Repeat keyboard for Nas-sys

by Richard Beal

In the last issue we printed a repeat keyboard routine for Nasbug T4. This can be adapted to Nas-sys, but we have now developed a routine which is simpler. This routine has given us an opportunity to show you the output of ZEAP 2.0, notice the sorted symbol table; there is a listing of the routine and a program to put the routine into use. Execute the program at OC90H.

The routine itself is from 0C80 to 0CF5H. After the program is executed it returns to Nas-sys. You can then use Nas-sys or execute ZEAP 2.0 or Basic and enjoy the benefits of a repeating keyboard. Just hold down any key, and after a delay it will repeat quite quickly, which is ideal for cursor movements. Try holding down several keys at once!! Note that the @ key does not repeat because of its dual function on Nascom 1. We also attach a tabulation of the code to make it easier to type in.

Memory usage and changing the speed

We hereby declare the following memory locations will for all time have the specified meanings:-

OC2C - OC2DH KCNT counter for repeat keyboard

OC2E - OC2FH KLONG delay before repeating starts

OC30 - OC31H KSHORT speed of repeating keys

These were unused locations in the Nas-sys work area. To change the initial delay before repeating starts, and the speed of repeat, change the values at KLONG and KSHORT.

Suggested values: 4MHz 2MHz
KLONG 0280H 0140H
KSHORT 0050H 0028H
The version overleaf is for 4MHz (Nascom 2).

Repeating keyboard from Basic

You can also set up a repeating keyboard within Basic, by typing in the Basic subroutine at lines 24000 to 24090. To execute it, type in: RUN24000

You will find that you then have a repeating keyboard. Note that line 24030 sets the speeds, we suggest the following values:

4MHz 2MHz
Initial delay DOKE 3118,640 DOKE 3118,320
Repeat rate DOKE 3120,80 DOKE 3120,40

```
0620; CLEAR KEYS DOWN
                                                       OCEO 7A
ZEAP Z80 Assembler - Source Listing
                                                                                  LD
                                                        OCE1 2F
                                                                      0640
                                                                                  CPL
              0010 : REPEAT KEYBOARD ROUTINE
                                                       OCE2 A6
                                                                      0650
                                                                                  AND
                                                                                        (HL)
              0020; WRITTEN BY RICHARD BEAL
                                                       OCE3 77
                                                                      0660
                                                                                  LD
                                                                                        (HL),A
                                                                      0670 ; NEXT ROW
0000
              0040
                           ORG
                                0
                                                       OCE4 23
                                                                      0680 RK7
                                                                                  INC HL
0000 0061
              0050 ZKBD
                           EQU
                                #61
                                                       OCE5 10E4
                                                                      0690
                                                                                  DJNZ RK3
0000 005B
              0060 ZMRET
                          EQU
                                                       OCE7 79
                                #5B
                                                                      0700
                                                                                  LD
                                                                                        A.C
0000 0072
              0070 ZNIM
                          EQU
                                #72
                                                       OCE8 B7
                                                                      0710
                                                                                  0R
                                                                                        A
0000 0070
              0080 ZSRLIN EQU
                                #70
                                                       OCE9 C8
                                                                      0720
                                                                                  RET
                                                                                        Z
0000 0076
              0090 ZUIN
                          EQU
                                #76
                                                                      0730 ; REPEAT SPEED
0000 0001
                          EQU
              0100 KMAP
                                                       OCEA 2A300C
                                                                      0740
                                                                                  LD
                                                                                       HL.(KSHORT)
0000 0020
                          EQU
              0110 KCNT
                                                       OCED 222COC
                                                                      0750
                                                                                  LD
                                                                                        (KCNT) HL
0000 0C2E
              0120 KLONG EQU
                                #OC2E
                                                                      0760 ; SCAN KEYBOARD
                                                       OCFO DF61
0000 0030
              0130 KSHORT EQU
                                #0C30
                                                                      0770
                                                                                  SCAL ZKBD
                                                       OCF2 C9
0000 0C7A
              0140 $UIN
                          EQU
                                #OC7A
                                                                      0780
                                                                                  RET
0000 0280
              0150 LONG
                          EQU
                                #0280
0000 0050
              0160 SHORT EQU
                                #0050
                                                                      0800 ; INPUT TABLE
                                                     00F3 76
                                                                      0810 RKT
                                                                                  DEFB ZUIN
                                                       OCF4 7000
              0180 : SET UP ROUTINE
                                                                      0820
                                                                                  DEFB ZSRLIN,O
0070
              0190 RKS
                          ORG
                              #0090
OC90 21F30C
              0200
                          LD
                                HL, RKT
                                                                      0840 ; END OF LISTING
OC93 DF72
                          SCAL ZNIM
              0210
                                                      ZEAP Z80 Assembler - Symbol Table
OC95 21BOOC
              0220
                          LD
                                HL,RK
OC98 227BOC
              0230
                          LD
                                ($UIN+1),HL
                                                       QC7AH 0140 $UIN
OC9B 218002
              0240
                          LD
                                HL, LONG
                                                                                OC2CH 0110 KCNT
              0250
OC9E 222E0C
                          LD
                                (KLONG),HL
                                                       OC2EH 0120 KLONG
                                                                                OC01H 0100 KHAP
                                HL,SHORT
                                                       OC30H 0130 KSHORT
OCA1 215000
              0260
                          LD
                                                                                0280H 0150 LONG
                                                       OCBOH 0310 RK
OCA4 22300C
              0270
                          LD
                                (KSHORT),HL
                                                                                OCBBH 0390 RK2
                                                       OCCBH 0490 RK3
OCA7 DF5B
              0280
                          SCAL ZMRET
                                                                                OCD4H 0540 RK5
                                                       OCDAH 0580 RK6
                                                                               OCE4H 0680 RK7
              0300 ; REPEAT KEYBOARD ROUTINE
                                                       QC90H 0190 RKS
                                                                              OCF3H 0810 RKT
                                                     0050H 0160 SHORT
                          DRG #OCBC
OCBO
              0310 RK
                                                                              0061H 0050 ZKBB
                                                     005BH 0060 ZMRET
OCBO DF61
              0320
                          SCAL ZKBD
                                                                               0072H 0070 ZNIH
                                                     0070H 0080 ZSRLIN
OCB2 3007
              0330
                          JR
                                NC,RK2
                                                                                0076H 0090 ZUIN
              0340 ; KEY PRESSED
OCB4 2A2EOC
              0350
                          LD
                                                            TC90 D00 0 0
                               HL, (KLONG)
OCB7 222C0C
                                                              0C90 21 F3 OC DF 72 21 B0 OC
              0360
                          LD
                                (KCNT),HL
OCBA C9
              0370
                          RET
                                                              OC98 22 7B OC 21 80 02 22 2E
                                                              OCAO OC 21 50 00 22 30 OC DF
              0380 ; KEY NOT PRESSED
OCBB 2A2COC
              0390 RK2
                         LD
                               HL,(KCNT)
                                                              OCAB 5B 00 00 00 00 00 00 00
OCBE 2B
              0400
                          DEC
                               HL
                                                              OCBO DF 61 30 07 2A 2E OC 22
OCBF 222COC
              0410
                          LB
                                (KCNT),HL
                                                              OCB8 2C OC C9 2A 2C OC 2B 22
OCC2 7C
              0420
                          LD
                                A.H
                                                              OCCO 2C OC 7C B5 CO 21 02 OC
OCC3 B5
                                                              OCC8 01 00 08 16 FF 7D FE 06
              0430
                          OR
                                1
OCC4 CO
              0440
                          RET NZ
                                                              OCDO 20 02 16 BF FE 09 20 02
                               CLEAR TABLE
HL,KMAP+1
BC,#0800
KK IN D
              0450 ; TEST AND CLEAR TABLE
                                                              OCD8 16 C7 7E A2 28 06 0E 01
OCC5 21020C
              0460
                          LD
                                                              OCEO 7A 2F A6 77 23 10 E4 79
OCC8 010008
              0470
                          LD
                                                              OCE8 B7 C8 2A 30 OC 22 2C OC
              0480 ; SET UP MASK IN D
                                                              OCFO DF 61 C9 76 70 00 00 00
OCCB 16FF
              0490 RK3
                          LD
                                D,#FF
                                                              QCF8 00 00 00 00 00 00 00
OCCD 7D
              0500
                          LD
                                A.L
OCCE FE06
                          CP
              0510
                                6
                                                    24000 REM ** SET UP REPEAT KEYBOARD
OCBO 2002
              0520
                          JR
                                NZ,RK5
                                                    24010 FORI=3248T03316STEP2:READJ:BOKEI,J:NEXT
                          LB
OCD2 16BF
              0530
                                B,#BF
                                                    24020 DOKE3195,3248:DOKE3189,3315
OCD4 FE09
              0540 RK5
                          CP
                                                    24030 DOKE3118,640:DOKE3120, 80:END
                                NZ,RK6
OCD6 2002
              0550
                          JR
                                                    24040 DATA25055,1840,11818,8716,3116,10953
OCD8 1607
              0560
                          LD
                                D,#C7
                                                    24050 BATA3116,8747,3116,-19076,8640,3074,1
              0570 ; TEST FOR KEY DOWN
                                                    24060 DATA5640,32255,1790,544,-16618,2558,544
OCDA 2E
              0580 RK6
                          LD
                                A,(HL)
                                                    24070 DATA-14570,-23938,1576,270,12154,30630
OCDB A2
              0590
                           AND
                               D
                                                    24080 DATA4131,31204,-14153,12330,8716,3116
```

24090 DATA25055,30409,112

OCDC 2806

OCRE OFOI

0600

0410

JR

1 m

Z,RK7

Γ.1

Program hints

By N.Ray

ONE OR TWO NOTES ABOUT Z80 MACHINE-CODE PROGRAMMING

Reading other people's Z80 code programs convinces me that many people are unaware of some very useful tricks.

For instance, although it is well-known that XOR A may be used to clear A (and the carry bit) the other operations on A have their uses.

E.g. AND A and OR A set Z and S flags from contents of A and may frequently replace CP \emptyset .

AND A (or OR A) can also be used to clear the carry flag if you don't mind corrupting the other flags. CP A will clear the Z flag.

A warning of general application is in order here.

```
AND A is not the same as CP \emptyset
INC A is not the same as ADD A,1 (Sim. DEC)
CPL, INCA is not the same as NEG
```

In each case the code on the left differs from that on the right in the way it affects the carry flag (and certain other flags).

While on the subject of programming dodges, here is an interesting example:

C: AND ØFH
ADD A, 9ØH
DAA
ADC A, 4ØH
DAA
\mathbf{RET}
•

The lower 4 bits in register A are interpreted as a hex digit and the corresponding hex character in ASC11 is found in A on exit. You should try to convince yourself that it works correctly (HINT: watch the half-carry flag).

RECURSION

Recursion can often be used to good advantage in machine-code programming, provided there is ample stack space. A recursive routine is one that calls itself. As a demonstration, consider the 'Tower of Hanoi' problem.

N rings are stacked on one of three poles (as indicated)

The problem is to move the rings from X to Z (using Y) by transferring one ring at a time from one pole to another, such that a larger ring is never placed on top of a smaller ring.

A recursive solution is:-

LET Move N from A to C using B
BE \$(IF N=0 RETURN

Move N-1 from A to B using C

Take top ring from A to C

Move N-1 from B to C using A \$)

The solution is then a call to 'Move N from X to Z using Y'. The solution is easily seen to be intuitively correct - 'Take' represents the action of moving a single ring. We can easily see that for N rings, the routine nests to a depth N, and Take is called 2 times.

I have sent a program for inclusion in the INMC library that runs on a minimal NASCOM and neatly demonstrates the correctness of the routine. It moves one ring for each press of any key.

In the program BC, DE, HL points at the 'poles' and N is stored in A.

It is arranged that BC, DE, HL always point at the top ring of a pole.

This program is also an excellent demonstration of the power of the Z80. I am able to keep all the variables in registers, thus saving on both execution time and storage space.

SOFT SPOTS (continued from page 8)

However, we hear that ZEAP 2.0 has been produced by the producers of ZEAP 1, and that it is a great improvement over the original. It has many useful features such as sorted symbol table. Also it will be available in either RAM (at 1000H) or ROM (at D000H) versions. It obviously makes better use of memory to run ZEAP in EPROM. It runs in 4K.

Zeap 2.0 runs only with Nas-sys, since it was designed for Nascom 2 owners, but it will of course run on a Nascom 1 fitted with Nas-sys. A version called ZEAP 1.2 has similar features and runs under Nas-bug.

Details such as price, and trade in offers for owners of ZEAP 1 will be available soon, so please don't write to us.

Just a simple little test (no prizes). What command can you enter to make Nas-sys un-resettable?



'us"





We've had a couple of letters recently saying that the newsletters are very nice and all that, but how can we be objective when we all work for Nascom. Well this has shown us that we have never bothered to tell you more than the sketchiest details of who we are, or for that matter, how we 'run' the INMC.

Can we make it absolutely clear that none of us, except Kerr Borland, work for Nascom. For the sake of those who have joined the INMC over the last year, we will tell you how this came about, and a bit more about ourselves. The Committee is a group of individuals who were, for various reasons, known to Nascom from before, or shortly after, the Nascom 1 launch. One night early last summer we met at the invitation of Kerr, and the idea of an 'ad hoc' INMC committee, to organize a newsletter, was tossed around. As the evening progressed, over certain liquid refreshments, a degree of amicable agreement was reached; to the extent that we ended up having to phone each other the following morning to find out what we had agreed to. At that time we were Richard Beal, Howard Birkett, Paul Greenhalgh, and David Hunt. Paul worked for Nascom, and we thought he would be good liason between us, and the product we were to support (may be we thought he would be a good source of inside information as well, but this did not prove to be the case). So over a period of time the first couple of newsletters saw the light of day, and our appeals for contributions started to be answered. Paul left Nascom, and strangely, Howard joined them. As Howard considered that he had too much of a vested interest in Nascom, he resigned from the INMC committee, to be replaced by two volunteers who had come to light amongst the membership; Derek Brough, and Eddie Pounce.

As far as the committee goes, our main resposibilty is to produce a newsletter once every couple of months (sometime perhaps we will reach our schedule), to keep an eye on the INMC library, and to act as a filter for, and if possible, answer any corespondence which can't be dealt with by dealers or Nascom engineering. In return for this, and our general support of the product, Nascom provide us with a letter box at Chesham, and secretarial services to handle distribution of programs from the library, and the newsletter mailing list.

We are independent of Nascom in most repects, although we appreciate the help they give us. The only stipulation (or better, restraint) imposed by Nascom is that we must not print derogatory comment on any other product which directly competes with Nascom, which makes sound commercial sense. We hope that we are objective in our aims, if Nascom ever 'lay an egg' over some product or other, we hope we will be the first to say so.

Just so you know a bit more about the INMC committee, we've each produced a 'potted' history. For professional reasons we will not name the Committees members' employers. So here goes:

Richard Beal has been with the committee from the start. He is 29, married and lives near Richmond Surrey. He has worked with computers for about 8 years, and until recently was a systems analyst. He is is now working for a large international management consultantcy. He owns a 16K Nascom 1 (which must qualify as being one of the first to come from Chesham), a 32K Nascom 2 running ZEAP, Naspen, and 8K Basic.

He also has an EPROM programmer, a Teletype 43 Terminal and an acoustic coupler. He is the designer of B-Bug, Nasbug and Nas-sys, which were all designed for his own purposes, and later made available to Nascom. His resposibility on the INMC is software problems, and software related corespondence.

Derek Brough joined the committee in October, is 36, is married with one child and lives in Barnet. He has a B.Sc, and is a lecturer in computing sciences at a London college. He has played with computers since school. He has an unexpanded Nascom 1 fitted with a number of hardware goodies, including joystick controls, and an interrupt driven IBM printer. He also has access to expanded Nascoms through his work (but says he usually can't get near them). He has recently undertaken the incredible task of re-assembling the complete INMC library so that the bulk of it may be used with Nas-sys. His main responsibility with the INMC is the library, and he is the nearest to Librarian we have got. He is also re-organizing the library to make sense of the various breeds of programs now coming in; ie: minimum system Nasbug, expanded system Nasbug, expanded

Kerr Borland is 35 and he says, "I was born to be a rich man's son, unfortunately, my father didn't work hard enough". He also says, "I am qualified for absolutely nothing, and spends most of my time doing what I am best qualified for!". He has also been known to say that he is a most likeable fellow, and we have noticed that he often tells us what a modest person he is. Kerr is Sales Director of Nascom, is married with one or more children (we are not sure whether it's us who don't know, or Kerr; Ed.), and lives in Totteridge. As president of the INMC he is our 'inside contact' with Nascom.

Paul Greenhalgh hails from the the north Country, is single, 24, and lives in Chesham. He has worked for an Electricity Board, and an electronic security firm and until recently he worked for Nascom. He is now employing his talents with a components supply company and Nascom distributor. He doesn't have a Nascom, but since leaving Nascom is saving his pennies to get one. He has tinkered with computers since leaving university, where he graduated with a B.Sc. On the INMC he is responsible for getting all the bits for the newsletter together, final editorial, pasteup, getting the newsletter printed, and distibution.

David Hunt is 34, lives in Harrow, has three children, and is still married despite his Nascom. He was trained as an electronics development engineer, leaving college with an HNC. After leaving the electronics field he went into retailing, starting in Hi-fi and later with a retail electronics company (not the same one as Paul), where he has been General Manager for the past five years. He has only been playing with computers for about 3 years, and was in the process of designing a kit for his company to market when Nascom 1 came along. He promptly dropped his own design, and is now a Nascom distributor. He owns a 32K Nascom 1 running Nas-sys and Nasbug, ZEAP, Naspen and 8K Basic. All firmware is kept on an 8K EPROM board, and his Nascom is fitted with programable graphics and high speed CUTS interfaces, he also has a TI 745 terminal. As INMC chairman, he keeps an eye on the hardware side of things, and acts as editor-before passing copy on to Paul.

Eddie Pounce joined the committee in October, is 27, is married with two children and lives in Watford. He has been playing with computers since leaving school, and throughout his university training, where he gained a B.Sc Hons. in computing. He is a data administrator for a large multi-national company working in London. He owns a Nascom 2 with Naspen, and fitted with an automatic double cassette I/O with auto. stop/start. He is equally at home with machine level code, Basic, and the hardware side of things, and has a general background in both mainframe, mini and micro computing. On the INMC he acts as sub-editor, and deals with technical corespondence.

So now you know who we are; as to the INMC itself, we meet about once every two months to chew over recent developments, and get feedback from each other. Corespondence is usually farmed out between members by post, and the letters are dealt with by the individuals, poor Paul seems to 'cop' most of them. Newsletter bits are usually rewritten (we call it editing) by Richard, Paul, Eddie and Dave, in most cases on Naspen tapes. Drafts are printed usually on the TI printer, and Paul and Dave have a late night session putting it all together to find out how much we've got. We usually aim for about 30 pages. If we are short of copy, some programs are rooted out and printed to make up the space.

Final editing is carried out on the Naspen tapes and printed on an IBM printer on A4 sheets, Paul then takes the lot, pastes it all up, filling spare bits as he goes. At this late stage Chas, is chivvied up to come up with another 'Lawrence' and any other line drawings required, and the whole lot sent to the printers. When it is all printed, the girls at Nascom get landed with seeing that they all get posted.

So thats who we are and what it is all about. The whole process usually takes about two months, and a lot of copy for the next newsletter is on file even before the previous one is 'put to bed'. So when you send us letters or copy, don't despair if it doesn't turn up in the next newletter, we're horrors for holding things over to the next issue. But the final message is we still need copy, keep it coming. We want reviews on MAPP1-3Z and the cheap colour graphics which is knocking around. We also want a review on any EPROM programmers. Please.

NASCOM 1 VDU PROBLEM - IC 18 MODIFICATION

Mr. L. E. Gilham of Bedfont asked us to clarify the position with regard to the modification to IC 18 to cure the problem with the VDU when a space is displayed where a letter should be.

The problem is around the timing of the character decoding in IC 16 and is corrected by:

- 1) Bending Pin 5 of IC 18 straight so that it is not connected when IC 18 is in the socket.
- 2) Connecting Pin 5 to Pin 12 of IC 18 on the underside of the board.

SOFTWARE LIBRARY

Below is the current list of Programs in the software library. No NAS-SYS machine code yet, but we should have some very soon. Prices are indicated by each program and postage charges are indicated below.

FRENCH MEMBERS please note that cheques in Francs are not accepted by British banks.

NASBUG/B-BUG MINIMUM SYSTEM MACHINE CODE

ASSEMBLY LISTINGS

D NA	Demonstruct .
Prog. No.	<u>Description</u> <u>Price</u>
Т1	<u>CRASH</u> 0C50-0FC9 £0.75
	Land the space-craft. Real Time. Can you make NASA proud of you? Commented teletype assembly listing. Machine code published in INMC 4.
	By H. Birkett
T2	REACTION TEST 0C50-0FCC £0.60
	When the random digit appears, press the same digit on the keyboard. Better than 0.6 seconds is good - how good are you? Commented teletype assembly listing Machine code published in INMC 3. By D. Hunt
Т3	BOUNCING BEASTIE ODOO-ODAB €0.20
	A character bounces around the screen leaving a trail behind it. Commented teletype assembly listing. Adapted by D. R. Brough
T4	REVERSE 0C60-0F88 £0.70
	Arrange the randomly generated list of numbers in order in the fewest moves by reversing any number of them at a time. Commented teletype assembly listing Machine code published in INMC 3. By H. Birkett
Т5	DOUBLE MASTERMIND 0C50-0FD5 €0.75
	Try and crack the NASCOM's four digit code while it tries to crack yours. (By the way, it won't let you cheat on the scoring!) Commented teletype assembly listing. Machine code published in INMC 2 By D. Ritchie
т6	POSSUM 0D00-0D84 £0.20
	The hex digits 1 to F are displayed and then flash one at a time. By pressing a button connected to the PIO socket, or any key on the keyboard, the ASCII

character corresponding to the code flashing will then be displayed. For use by the severely disabled. Commented teletype assembly listing.

By F. Butler, modified by D. Brough

T7 JJ 0C50-0DE5

£0.40

Enter the machine code listing of this (in INMC 3) before seeing how it works. Written as an experiment in machine code string handling, but entertaining neverthe less. Commented teletype assembly listing.

By H. Birkett

T8 UNIZAP ODOO-0F74

£0.75

Recreate the life of the universe. Take it from the "big bang" to its "ultimate destiny" by shooting stars. Based on "Shooting Stars" in Byte magazine, May 1976. Commented teletype assembly listing.

Adapted by D. R. Brough

T9 RANDOM BUZZ-WORD LINKER 0C50-0F35

£0.50

Short of jargon? Then use this "Functional organisational flexibility" to give you "Limited transitional communication" in your "Balanced digital engineering". Commented teletype assembly lisiting. Machine code published in INMC 4.

By D. Hunt and R. Beal

T10 QUIZ PROGRAM 0C50-0DAA plus ITALIAN FILE 0DB0-0FD9

£0.65

What is Italian for Please, or English for Fratello? Find out how good your Italian is with this quiz. Also additional files (e.g. Capitals, Cockney, Rhyming slang) available soon. Commented teletype assembly listing.

By M. Bell

T20 ROBOTS 0C70-0FE6

£0.60

Six homicidal robots chasing you across a field of electrified pylons. The robots head directly towards you and so by careful movement you can persuade them to electrocute themselves on the pylons. Speed and difficulty selectable from einch to impossible! Good instructions, teletype assembly listing, no comments.

By H. Birkett

T21 T.V. TEST PATTERN 0D00-0D19

£0.10

Displays test pattern of "+" symbols on screen to set up colour T.V. Well commented.

By R. Cogliatti

T22 NIM 0D00-0FC4

£1.20

The classic game of Nim. Nicely commented with good instructions.

By N. A. Purver

T23	ATTACK ODOO-OE7F £0.50
	Shoot the descending aliens before they get you! Commenting fair. By M. R. Perry
T24	OCTAL TO HEXADECIMAL CONVERTOR ODOO-ODBC £0.25
	Rejects all illegal input characters. Well commented. By J. Hill
T25	SPACE-INVASION 0C50-0FD2 £1.20
	Very similar to the game seen in many amusement arcades As you get better, it gets harder. Addictive. Well commented. By G. Clarke
T26	DIGITAL CLOCK ODOO-OD7B £0.30
	Simple 24 hour digital clock (hours, mins., secs.) Nicedemo of arithmetic and counter manipulation. Well commented but ties up processor 100% By B. C. Winch
T27	ROADRACE 0C50-0FE0 £0.85
	Steer your car home with minimum damage. Choice of speed Addictive. Well commented. By M. Parker-Rhodes
T28	DECIMAL TO HEXADECIMAL CONVERTOR 0C90-0D07 £0.15
	Nicely commented. Poor input validation. Positive numbers only. By G. Harriman
T29	<u>LIFE</u> 0C50-0FA0
	The ubiquituous simulation of life, using special characters to give an expanded Universe. Works well, very fast, good instructions, well commented. By J. Haigh
T30	MOON-LANDER 0C50-0FEC £1.50
	Ingenious moon-landing program using keyboard as "crash-pad joystick". Below 2500ft display expands to terrain map, and when you land, look out for those boulders. Well commented, good instructions, teletype assembly listing. INMC games competition winner - object code listing in INMC issue 3.
	Submitted by N. Ray
T31	COMPACT ASCII EDITOR 0F70-0FDF £0.15
	Crude editor allowing ASCII characters to be located and changed. Well commented, good instructions. (Nice demonst very practical). By A. Fountain
T32	CARRE CHINOIS 0C50-0F3F £1.50
	We have no idea what this game is or what it does (we ain't French is we?) Totally written (and presumably (?) beautifully commented) in French. By G. Bochent

T33	LOLLYPOP LADY TRAINER 0C60-0F95 £0.70
	See if you can get the chickens across the road without getting them run over. Well commented.
	By M. Parker-Rhodes
T34	RANDOM I-CHING CHARACTER GENERATOR 0C50-0CF3 £0.30
	Great mystical significance (for those who understand these things). Nicely commented.
	By C. Blackmore
T35	<u>WALLED CHASE</u> 0C50-0E27
	For two players, one chases the other but here are invisible walls in the way, which appear when you hit them. Fascinating game, well commented.
	By S. Montgomery-Smith
Т36	SUB-SEARCH 0E0B-0F31 £0.50
	Ship traverses screen dropping random depth charges on randomly moving submarines.
	By T. Bailie
Т37	RANDOM DISPLAY 0C60-0C84 £0.10
	Displays random pattern of asterisks. Nicely commented. By G. Harriman
T38	<u>SUBMARINES</u> 0C60-0E50 £0.50
	Hit the randomly displayed submarines with your steerable depthcharges. Good instructions, no comments.
	By N. D. Wallbridge
T39	BURST THE BALLOON 0C50-0E02 £0.70

Shoot the balloons as they make their way up the screen, at the mercy of random breezes. Well commented, good instructions.

By J. Waddell

Postage and Packing
UK customers please add 15p per order, overseas customers 40p.

A NOVEL WAY OF EXPANDING A NASCOM 1

Suggested by Mr. L. E. Gilham of Bedfont.

If you have a 1K monitor on a NASCOM 1 a convenient way of expanding by 1K is to put a MK4118 (1K x 8) in the spare EPROM socket. This is done by bending Pins 18,19,20,21 straight and connecting them to CE (old Pin 20), +5v, RD, WR respectively either by putting the chip in a socket and then bending this socket and putting it in the socket on the board or by bending the chip pins and using 'Soldercon' pins. This will give another 1K of RAM from 0400H to 07FFH.

8K Basic programs

81	Hello Is your problem health, sex (yes please), money or your job? Let this fun program make some suggestions.
B2	Russian Roulette 0.20 Will you or your Nascom survive as you take it in turns to fire a revolver at yourselves.
B3	Startrek A real-time version of this popular program where your mission, as Captain of the Enterprise, is to wipe out the Klingons before your time is up and the ship's energy runs out.
34	Cubist Art Impress the neighbours with the artistic capability of your Nascom. Sort of animated wallpaper. (Graphics required).
35	3D Noughts and Crosses Play against the Nascom on a 4 x 4 x 4 board. Can you beat it or, more difficult, can you take it to a draw. A prize for the first person to convince us that he took it to a draw.
В6	Calender Enter the year required (between 1601 and 2399) and let the Nascom calculate the calender for that year.
В7	Magic Labyrinth You are in a 5 level labyrinth, and your quest is to find the 5 Objects of State, one on each level. To make matters more interesting there are good, neutral and evil creatures that lurk in the labyrinth, which may help or hinder you as they feel fit.
B8	With this program loaded, your Nascom is specially trained in psychoanalysis. What are your particular hangups? (A full listing appeared in INMC 5.)
89	You have stolen the priceless idol belonging to a tribe of knock-kneed pigmies. They want it back and are in hot pursuit. You are in the desert, on a camel!! Can you reach safety before the pigmies (or wild Neringi Berbers) catch you?
B10	Comrade X You are premier of the communist island of Niatirb. You must decide your country's budget, harvest, and economic strategy.

The above are all available from the library, singly, at the above prices (+ 15p UK postage, 40p overseas per order), or as Basic Programs Book 1 which also includes other goodies at 2.50 (+ 40p UK postage, 95p overseas).

revolt, or you are exiled (or something worse)?

You have 8 years in office, can you survive before the peasants

Piranha by J & E Long Re-assembled for Nas-sys by Richard Beal. Execute at 1000H

T 1000 18E2 1000 31 00 10 CD D5 14 CD 49 1E 1008 15 CD 8 E 10 CD DA14 21 74 1010 5F 13 7 E FE 4F 28 OC E5 7B 1018 CD 3 E 10 **3**A B7 15 **B7** F4 54 CD 00 12 CD 1F 7 E 1020 30 12 E1 11 21 18 F1 1028 11 CD 2 D 5E 06 56 1030 16 C 5 E5 CD 13 E1 CD E4 15 C110 F4 3A **B7** 15 8E 1038 66 FF 20 04 3E 20 18 02 E9 1040 FE 1043 3E 41 32 F6 0B 13 CO 21 03 1050 CC 0 B 11 9F 15 06 17 1A 33 13 23 10 FA 3A B9 15 27 1058 77 30 32 E3 0B 07 93 1060 C6 30 **D6** C2 1068 07 0.7 16 0.0 5F 2A 15 FC 15 06 1070 11 0.8 7E 12 17 19 BA 10 13 FA AF 32 90 15 4 E 1078 23 1080 C9 **3**A **B9** 15 FE 03 **C8** 3C БÇ C₂ 29 1088 32 39 15 18 E1 CD 49 1090 12 FE 30 D8 FE **3A** D0 D6 96 15 B9 1098 30 32 B9 13 B1 3A 34 15 3C 47 21 54 0B CD DB 10 CACL 10 10 FΒ 21 52 18 56 23 E7 10A8 CD 13 15 BA 10B0 5 Z AF. 3A 38 GD 1038 20 19 FE 01 20 04 3E 2E 90 10C0 18 02 01 32 38 15 3A 32 3 E 10C8 C1 15 47 21 F4 03 CD E9 CB 10 F8 3A 90 15 FE 14 E 9 1000 10 10D8 C0 18 A6 3A **B6** 15 3C 32 D915 FE 20 CO AF 32 B6 30 10E0 B6 20 10E8 15 7E FE 20 03 36 31 33 10F0 C9 FE 39 C2 FΒ 10 35 30 33 18 10F8 23 ΕE 3C 77 C9 7E FΕ 31 FΕ 28 30 20 1100 20 16 05 36 F8 18 F2 3D 77 FE 30 69 1108 39 2B 1110 CO 2B 3 E 20 BE CO 23 77 82 1113 C9 3 E FF 32 B7 15 C9 21 17 1120 3F 15 34 C0 23 34 CO 23 03 23 15 1128 34 CO 34 Ç9 3Λ BA 56 1130 CD CA 11 FE 0.1 CO 3E 0.8 ΕE CA 11 **B7** CO CD **A7** 14 F0 1138 CD 1140 70 08 36 B5 01 23 3E 64 46 1148 CD CA 11 47 3A BF 15 B8 0E 04 36 41 18 02 36 49 **A5** 1150 30 1153 23 3A BD 15 CD CA 11 47 87 1160 3A ВC 15 30 77 2B 2B 77 40 15 E5 CD 80 1168 CD 69 3A BB 15 02 1170 CA 11 FE 03 23 2D FΕ **B**2 FΕ 00 CO **C7** 1178 23 1D 01 28 06 1130 3E 2E 21 4AOB. 11 01 00 85 1183 18 23 06 40 3E 2E 21 4A F1

1190 03 11 01 00 C3 AD 11 06 42 1198 FF 35 0 D 21 38 08 11 40 A5 11A0 00 18 0A 06 01 3E OD 21 46 08 11 0.0 CD 11A3 0.8 40 CA 11 C5 11B0 3C 19 3D 20 FC EB E1 1A 55 **11B8** FE 20 28 05 2B 2B 36 AF EF 1100 C9 70 23 72 23 73 2A 3E 9D 11C8 12 C9 C5 E 5 47 2A 8D 15 71 1100 0E 03 7C 0F AC AC 0F 0F F8 11D8 0F AD 0F 0F OF EE 01 E6 **A7** 20 11E0 01 29 85 6F 0 D EΒ 22 49 11E8 8D 15 7 C 35 G778 6F 80 6A D6 11F0 **B8** 30 FB 7C BD 30 B8 DB 11F8 38 03 90 18 FA E1 C1 C9 51 2B 1200 DF 62 00 D0 36 01 CD 52 1208 69 15 E 5 21 EΑ 17 08 1C 1210 BE 28 05 23 10 FA E1 C3 E4 1218 3 E 10 90 E6 FE 21 CE 17 ΞE 1220 16 5F 19 5E 23 0.0 56 EB1228 E9 CF C9 00 35 CO 18 1A EB 1230 3E 01 13 16 3E 40 18 12 57 0E 1238 3E FF 18 3E BF 18 OA CC 1240 3 E C1 18 05 3E 41 18 02 0.8 23 1248 3E 3F E1 BE 05 77 2B 45 1250 36 2C C9 2B 36 0.0 C9 E1 **A4** 1258 36 0.0 C 9 EI 3A B 7 15 2F 7 F 1260 32 B7 15 СЭ 01 EΞ 17 11 50 1268 05 18 21 3 C 08 E5 1A 13 5 F 1270 FE FF CA 0.0 10 77 FE 23 F1 1278 2D 20 F3 CD 23 12 FE 21 F1 1280 CA 00 10 02 03 03 77 E1 CC 1283 **D5** 11 40 0.0 10 D118 DD 9F 1290 21 5 E 18 7 E FΕ 01 CO 3A B0 1298 F1 0B FΕ 20 C3 21 F4 0B AC 12A0 CD 21 FΕ 10 62 18 46 23 91 CD 12A8 4 E 07 13 57 2B 2 B 7 E 1A 12B0 B 7 20 0 C 3A 38 15 FΕ 01 AB 12B8 3E FF 28 02 3 E 01 77 CD B4 5F 12C0 13 83 46 07 5F 0F **B**3 35 12C8 5F A2 B7 C8 06 07 3A **D7** 78 12D0 12 EE 08 32 **D7** 12 **7B** 0.7 87 28 12D8 5F A2 **B7** 15 10 F 7 **7B** 61 12E0 07 07 A3 5F 06 08 7B 0F 9A 12E8 5F A2 **B7** 28 0B 10 F 7 36 22 12F0 0.0 C9 **7**B 0.7 5F 0 F OF **A3** 60 12F8 CD 13 06 10 21 F3 40 77 CB 1300 0B CD FE 10 10 F3 C9 E5 AF 1308 21 74 15 AF 32 8 C 15 3 E 8.5 32 1310 80 3B 15 7 E **B7** 5F 16 **A7** 1E 1318 0.0 F2 13 16 EE EB 09 57 1320 7E EΒ 23 FE 20 28 0C FΕ 0 F 1328 25 28 56 3A 08 8 C 15 82 43 23 1330 32 8C 15 23 3Α 8B 15 36 1338 3 C 3D 20 **D**6 3A 15 E1 09 03 1340 15 E5 21 73 18 04 E5 21 03 1348 74 15 BE 28 05 CD 69 15 1A

23

E2

16

90

10

09

EE

9F

67

97

DD

90

10

6A

53

29

F9

E3

53

D8

C1

F2

DD

18

77

3F

5D

7F

A2

C4

25

3B

22

25

4 F

CE

10

2D

1A

BA

A₀

39

57

47

93

90

CO

4D

29

```
1350
       18
          F3
              23 7E E1 C9 35
                                 CO
                                     B3
                                               1510
                                                     5E
                                                        18
                                                            36
                                                                2 C
                                                                    23
                                                                        35
                                                                            50
       3E
           01
 1358
              CD
                  CA
                      11
                          B7
                              CO
                                  23
                                     EC
                                               1518
                                                     36
                                                         2C
                                                            23
                                                                36
                                                                    00
                                                                        23
                                                                            01
 1360
       7E
           FE
               4F
                  C8
                      FE
                          58
                              CA
                                 9B C1
                                               1520
                                                            23
                                                     9
                                                        70
                                                                71
                                                                    3E
                                                                        07
                                                                           02
 1368
       14
           E 5
              FE
                  49
                      CC
                          C6
                              13
                                 E1
                                     41
                                               1528
                                                     15
                                                        23
                                                            23
                                                                36
                                                                    4F
                                                                        CD
                                                                           68
                                                                               15
 1370
       23
           7 E
              2B
                  2B
                      77
                          CD
                              69
                                 15
                                     3C
                                              1530
                                                     15
                                                        20 F6
                                                                21
                                                                    E9
                                                                        0B
                                                                           06
 1373
              5E
       16
           00
                  7B
                      B7
                          C8
                              B7
                                 F2
                                     A2
                                              1538
                                                     11
                                                        93
                                                            15
                                                                1A
                                                                    77
                                                                        13
                                                                           23
 1380
       84
           13
               16
                  FF
                      23
                          46
                              23
                                 4E
                                     19
                                              1540
                                                    FA
                                                        3E FF
                                                                32
                                                                    B7
                                                                        15
                                                                           C3
                                                                               4F
 1388
       0A
          FE
              20
                  20
                      06
                          CD
                              6E
                                 15
                                     39
                                              1548
                                                     10
                                                        21
                                                            4 D
                                                                08
                                                                    06
                                                                       0.0
                                                                               14 1B
                                                                           11
 1390
       36
          4F
              C9
                  E 5
                      60
                          69
                              19
                                 EB A3
                                              1550
                                                     16
                                                        E5
                                                            1A
                                                                13
                                                                    FE
                                                                       40
                                                                           28
                                                                               04 F7
 1398
       E 1
          1A
              FE
                  25
                      CA
                          2 E
                              14
                                 FE
                                     D3
                                              1558
                                                     77
                                                        23
                                                            18
                                                                F6
                                                                    E1
                                                                       D5
                                                                           11
                                                                               40
 13A0
       20
          C2
              40
                  14
                      2B
                          72
                              23
                                 73
                                     10
                                              1560
                                                    00
                                                        19
                                                            D1
                                                                10
                                                                   EC
                                                                       C9
                                                                           23
                                                                               23
 13A8
          12
       0A
              3E
                  20
                      02
                          C9
                              C 5
                                 21 E6
                                              1568
                                                    23
                                                        23
                                                            23
                                                                23
                                                                   C9
                                                                       2 B
                                                                           2B
                                                                               2B
 13B0
       F6
          F7
              19
                  11
                      CO
                          FF
                              06
                                 10
                                     AF
                                              1570
                                                    2B 2B
                                                           C9
                                                                01
                                                                   CO
                                                                       01
                                                                           02
                                                                               C1
 1338
       19
          05
              7C
                  B7
                      F2
                          B8
                              13
                                 58
                                     31
                                              1578
                                                    02
                                                        04
                                                            01
                                                                04
                                                                   08
                                                                       41
                                                                           0.8
                                                                               10
 13C0
       7D
          C6
              40
                  57
                      C1
                              3 E
                          C9
                                 64
                                     D9
                                              1580
                                                    40
                                                        10
                                                            20
                                                                3F
                                                                    20
                                                                       40
                                                                           FF
                                                                              40
13C8
       CD
          CA
              11
                  47
                      3A
                          CO
                              15
                                 B8
                                     91
                                              1588
                                                    80
                                                        BF
                                                            80
                                                                01
                                                                   00
                                                                       BB
                                                                           70
                                                                               D1
13D0
       D8
          CD
              69
                  15
                      E5
                          56
                             23
                                 5E
                                    C2
                                              1590
                                                    37
                                                        00
                                                            00
                                                                53
                                                                   63
                                                                       6F
                                                                           72
                                                                               65
13D3
      CD
          ΑE
              13
                  42
                      4B
                          3A
                             52
                                 18
                                     BA
                                              1598
                                                    20
                                                        20
                                                            20
                                                                20
                                                                   20
                                                                               2A C7
                                                                       20
                                                                           30
13E0
          3A
       57
              63
                  13
                      5 F
                         CD
                             ΑE
                                 13
                                     EC
                                              15A0
                                                    2A
                                                       20
                                                            50
                                                                49
                                                                   52
                                                                       41
                                                                           4 E
                                                                               48
13E8
      78
          32
              57
                  FE
                      7F
                         38
                                 2F
                             01
                                     41
                                              15A8 41
                                                       20
                                                            2A
                                                                2A
                                                                   20
                                                                       20
                                                                           20
                                                                               20
13F0
      47
          79
              93
                  5 E
                      B7
                         F2
                             F9
                                 13
                                     6A
                                              15B0
                                                    50
                                                        68
                                                            61
                                                                73
                                                                   65
                                                                       20
                                                                           07
                                                                               0.0
13F8
      2F
          B8
              38
                  0D
                      7B
                         B7
                             FA
                                 05
                                     68
                                              15B8 2E
                                                       09
                                                            28
                                                                04
                                                                   28
                                                                       3C
                                                                           20
                                                                               64
1400
      14
          3E
             40
                  18
                     0F
                         3E
                             CO
                                 18 E3
                                              15C0 1C
                                                        FF
                                                            C4
                                                                   48
                                                                15
                                                                       01
                                                                          05
                                                                               60
1408
      0B
          7A
              B7
                  F2
                     12
                         14
                             3E
                                 01 AF
                                              15C8
                                                    30
                                                        0A
                                                            01
                                                               32
                                                                   48 01
                                                                           50
                                                                               5C
1410
      13
          02
              3E
                  FF
                     E1
                         2 B
                             47
                                     4C
                                 7E
                                              15D0 30
                                                        14
                                                            04
                                                               4B
                                                                   44
                                                                               58
                                                                       01
                                                                          48
1418
      88
          C3
              2F
                  B3
                      28
                         02
                             70
                                C9
                                     F6
                                              15D8 2C
                                                        1E
                                                           07
                                                               64
                                                                               54
                                                                   44
                                                                       01
                                                                          44
1420
      FΕ
          CO
              28
                  07
                     FE
                         40
                             28
                                 03
                                     8A
                                              15E0 2C
                                                        28
                                                            0A
                                                               7D
                                                                   40
                                                                       02
                                                                          40
                                                                               50
1428
      36
          40
              C9
                  36
                     01
                         C9
                             CD
                                 5E
                                     BG
                                              15E8
                                                    28
                                                        32
                                                            0D
                                                               96
                                                                   40
                                                                       02
                                                                           3C
                                                                              4C
                  50
                     28
1430 15
          7E
             FE
                         05
                             2B
                                CD
                                     4A
                                              15F0
                                                    28
                                                        3C
                                                           10
                                                               AF
                                                                   38
                                                                       02
                                                                          38
                                                                              48 E2
1438 9A
          14
              C9
                  AF
                     23
                         23
                             77
                                 C9
                                     F8
                                              15F8
                                                   24
                                                        46
                                                           13
                                                               C8
                                                                   38
                                                                       0.2
                                                                          34
                                                                              44 04
1440
      CD
              15
                     9A
          6D
                  CD
                         14
                             CD
                                 BB
                                    A6
                                              1600
                                                   24
                                                        50
                                                           16
                                                               E1 30
                                                                          30
                                                                       04
                                                                              40
1448
      14
         CD
              9A
                  14
                     21
                         01
                             00
                                -09
                                     16
                                             1608
                                                   20
                                                        5A
                                                           19
                                                                   28
                                                               FA
                                                                       04
                                                                           28
                                                                              3C
1450
      CD
          69
              14
                  21
                     FF
                         FF
                             09
                                    A3
                                 CD
                                             1610
                                                   20
                                                        64
                                                           1C
                                                               FF
                                                                   59
                                                                       6F
                                                                          75
                                                                              20
1458
      69
          14
              21
                  40
                     00
                         09
                             CD
                                 69
                                     89
                                             1618 68
                                                       61
                                                           76
                                                               65
                                                                   20
                                                                       66
                                                                          61
                                                                              6C
1460
      14
          21
                  FF
             CO
                     09
                         CD
                             69
                                 14
                                    BB
                                             1620 GC
                                                       55
                                                           GΕ
                                                               20
                                                                   69
                                                                       6E
                                                                          74
                                                                              6F
      C9
1468
          7E
              FΕ
                  20
                     CA
                         30
                             14
                                 FE
                                    3D
                                             1628
                                                   20
                                                        74
                                                           68
                                                               65
                                                                   20
                                                                      41
                                                                          6D
                                                                              61
1470 25
          C8
              FE
                 2B
                     C8
                         E5
                            C5
                                 ΕB
                                    F 7
                                             1630
                                                   7A
                                                       6F
                                                           6E
                                                               2C
                                                                   20
                                                                       51
                                                                          6E
                                                                              64
1478 CD
         BB
              14
                 CD
                     9A
                        14
                             C1
                                 E1
                                    45
                                             1638
                                                   40
                                                       20
                                                               75
                                                           6D
                                                                   73
                                                                       74
                                                                          20
                                                                              61 F8
1480 EB
          C5
             CD
                             7C
                 A7
                     14
                         C1
                                 B5
                                    BE
                                             1640
                                                    76
                                                       6F
                                                           69
                                                               64
                                                                   20
                                                                       74
                                                                          68
                                                                              65 69
1488
     C8
          3A
             BE
                 15
                     77
                         23
                             36
                                 58
                                    99
                                             1648
                                                   20
                                                       6D
                                                           61
                                                               6 E
                                                                   2D
                                                                      65
                                                                          61
                                                                              74 21
1490
     CD
          63
              15
                     23
                  72
                         73
                             3E
                                2B
                                    60
                                             1650
                                                   69
                                                       6E
                                                           67
                                                               20
                                                                  50
                                                                      69
                                                                          72
                                                                              61 50
1433
      12
          C9
              23
                 36
                     4F
                         CD
                             69
                                15
                                    7A
                                             1658
                                                   6E
                                                       68
                                                           61 21
                                                                  40
                                                                       50
                                                                          72
                                                                              65
14A0
     46
          23
             4E
                 3E
                     20
                         02
                             C9
                                21
                                    B5
                                             1660
                                                   73
                                                       73
                                                           20
                                                               61
                                                                  6E
                                                                       79
                                                                          20
                                                                              6B 4F
14A8
      65
         18
             06
                 15
                     7E
                        FE
                             4F
                                28
                                    47
                                             1668
                                                   65
                                                       79
                                                           20
                                                               74
                                                                   5F
                                                                       20
                                                                          73
                                                                              74 66
1480
      0.8
         CD
             66
                 15
                     10
                         FG
                             21
                                01
                                    3C
                                             1670
                                                   61
                                                       72
                                                           74
                                                               20
                                                                  20
                                                                      6F
                                                                          72
                                                                              20
14B8
          2B
      0.0
             C9
                 21
                     5 E
                         18
                             06
                                16
                                    73
                                             1678
                                                   30
                                                       2D
                                                           39
                                                               20
                                                                  74
                                                                      6F
                                                                          20
                                                                              73
14C0
      CD
         68
             15
                 7 E
                     23
                         BA
                             20
                                0.7
                                    A0
                                             1680
                                                   65
                                                       74
                                                           20
                                                               70
                                                                  68
                                                                      61
                                                                          73
                                                                              65
14C8
      7E
         BB
             20
                 03
                     C3
                        6D
                             15
                                23 A0
                                             1688
                                                   2E
                                                       40
                                                           50
                                                               72
                                                                  65
                                                                       73
                                                                          73
                                                                              20
14D0
      10
         EE
             21
                 0.0
                     0.0
                        C9
                             AF
                                32
                                    AD
                                             1690
                                                       20
                                                   48
                                                           74
                                                               6F
                                                                   20
                                                                      73
                                                                          74
                                                                              6F
14D8
      39
         15
             21
                 00
                     08
                         06
                             10
                                0E
                                    07
                                             1698
                                                   70
                                                       2C
                                                           20
                                                               6F
                                                                  72
                                                                      20
                                                                          74
                                                                              68
14E0
      40
          36
             20
                 23
                     0D
                         20
                             FA
                                10
                                    E4
                                             16A0
                                                   65
                                                       20
                                                           61
                                                               64
                                                                  6A
                                                                      61
                                                                          63
                                                                              65
14E8
      F6
         21
             0A
                 08
                     11
                         8A
                             0 B
                                06 D1
                                             16A8
                                                   6E
                                                       74
                                                           20
                                                               6B
                                                                  65
                                                                      79
                                                                          73
                                                                              20
14F0
      30
         3E
             25
                 77
                     12
                         23
                             13
                                10
                                   66
                                             16B0
                                                   74
                                                       6F
                                                               20
                                                           40
                                                                  6D
                                                                      6F
                                                                          76
                                                                              65
14F8
      FA
         06
             0 E
                 21
                     4A
                         0.8
                             77
                                0E
                                    12
                                             16B8
                                                   20
                                                       69
                                                           6E
                                                              20
                                                                  61
                                                                      6E
                                                                          73
                                                                              20
1500
      2F
          23
             OD.
                 20
                     FC
                         77
                             0E
                                11
                                    26
                                             16C0
                                                   64
                                                       69
                                                           72
                                                              65
                                                                  63
                                                                      74
                                                                          59
                                                                              6F
      23
1508
             20 FC
         OD.
                    05
                        20
                            EF
                                21
                                   9 E
                                             16C8 6E 2E 20
                                                              20 50
                                                                     72 65 73 54
```

```
16D0 73
         20 6B 65 79
                         20
                            74
                                77
                                    CD
16D8 69
         63
             65
                 40
                    20
                         74
                            6E
                                20
                                    82
             76
                 65
                     20
                         6 D
13E0
      6D
          65
                            6F
                                72
                                    1B
16E8
     65
          20
             71
                 75
                     69
                         63
                            6B
                                    O.C.
                                6C
      79
          2E
             40
                 53 77
                            5D
                                20
                                    AD
16F0
                         69
         72
             6F 6D
                    20
16F3 66
                         73
                            69
                                64
                                    22
             74 6F
                     20
1700
      55
          20
                         73
                            59
                                    DF
                                64
1708 65
          20
             66
                 5F
                     72
                         20
                            62
                                6F
                                    DC
         75
                 20
                            69
                                6E
                                    53
1710 SE
             73
                     70
                         6F
         73
             2E
                40
                            55
1718
      74
                     57
                         68
                                GE
                                   16
                     20
1720
      20
         74
             68
                 65
                         73
                            63
                                6F
                                    FD
1728
      72
         65
             20
                 69
                     73
                         20
                            6F
                                76
                                    17
                            30
1730
      55
          72
             20
                 31
                     30
                         30
                                2C
                                    2B
1738 20
          74
             75
                 72
                     6E
                         20
                                    35
                            6F
                                6E
1740 20
         6F
             72
                40
                     20
                         6F
                            66
                                66 F3
1748 20
         61
             75
                 74
                    6F
                         70
                            63
                                GC - 7D
             20 62
1750 SF
          74
                     79
                                72 47
                         20
                            70
1758
      65
          73
             73
                 6.3
                     6E
                         67
                            20
                                41
                                    53
1760 2E
         40
             50
                 72
                    65
                         73
                                20
                            73
                                   12
         20
                58
1768 50
             74
                    65
                         6 E
                            20
                                30 EE
1770
      2D
         39
             20 74
                    6F
                         20
                            73
                                65
                                   E8
                 68
      74
          20
             70
                     61
                         73
                            65
                                2 E
                                    62
1778
          50
                 65
                                    57
1780
      40
             72
                     73
                         73
                            20
                                53
1788 20
         66
                 72
                     20
                         6E
                            65
                                    70
             6F
                                77
1790 20
          67
             61 6D
                    65
                         2E
                            40
                                50
                                   1 F
1798 72
          65
             73
                 73
                     20
                         21
                            20
                                74 41
             63
                 68
17A0
      6F
          20
                     61
                         6E
                            67
                                65
                                    AC
17A8 20
          6B
             65
                 79
                     73
                         20
                            75
                                73
                                   A3
17B0 65
         64
             2E 40
                    50
                         72
                            65
                                   98
                                73
1788
     73
          20
             22 20
                     74
                         6F
                            20
                                6C
                                    13
1700
      65
             76 65
                     20
                         70
                            72
                                6F E9
         61
          72
             61 6D
                     2E
                                   F4
17C8
      67
                         40
                            0.0
                                00
                         12
17D0
      64
          12
             0.0
                 10
                     2C
                            34
                                12
                                    F1
     38
         12
             30 12
                     3C
                         12
                                12
17D8
                            40
                                    1B
17E0
     48
         12
             44
                 12
                     57
                        12
                            8D
                                10
                                   AD
17E8
      5B
         12
             22 22
                     21
                        21
                            53
                                0 D
                                    52
                 32
      59
          33
             4 E
                     47
                         34
                            4A
                                36
                                    13
17F0
17F8
      54
          37
             55
                 33
                     42
                         31
                            4 D
                                33
                                    18
1800 48
          35
             50 2E
                    41
                         30
                            4E
                                65
                                    37
1308 77
          20
             67 61
                     6D
                        65
                            2 D
                                55
                                    D3
      70
          2D
             44
                 6F
                     77
                         6 E
                            2 D
                                4 C
                                   D6
1310
1313
      65
          66
             74
                 2D
                     52
                         69
                            57
                                68
                                    26
      74
          2D
                 70
                     2C
                         5C
1820
             55
                            6.5
                                66
                                    01
                     20
1328
     74
          2D
             55
                 70
                         72
                            69
                                67
                                    14
1330 53
          74
             2D
                 44
                     GF
                         77
                            GE.
                                2C
                                    15
1838 5C
         65
             55
                 714
                     2D
                        44
                            G.F
                                77
                                    52
          20
             72
                 69
                     67
                         68
                             74
                                2 D
1840
      SE
                                    3D
1848
      43
          61
             6C
                 74
                     2D
                         50
                             68
                                61
                                    2 F
1350 73
          55
             2D
                 41
                     75
                         74
                            6F
                                70
                                    76
1858 69
          60
             5F
                 74
                     2 D
                        FF
                            BF
                                4F
                                    62
1850
      20
         01
             0A 16
                     01
                        49
                             60
                                FF
                                    6E
      0A
          AF
             28
                 49
                     2F
                         FF
                             08
                                72
                                    52
1363
      02
          4F
             46
                 FF
                         D4
                             02
                                4F
                                    4D
1370
                     0A
                 15
1378 5C
          CO
             03
                     00 49
                            2F
                                40
                                    84
1880 OA
         58
             03 4F
                     2D CO 0A
                                95 D8
1888 13
          4F
             3D 40 0A 93 22
                                4F
                                    8D
```

1890 61 CO OA D4 5F 4F 44 40 D9 12 1898 0 B 53 4 F 32 CO ŊΑ 3 F D41.2 4F 2D 40 18A0 OA. 54 **1**A 4 F 4 D 18A8 3A FF 09 D6 1A 4F 25 65 FF 18B0 09 56 83 4 F 3E CO 0.9AC AC 4 F 18B8 83 2A FF 2 C E 5 4F 03 34 1800 1B 40 09 2A D6 4 F 4F 00 DA 1308 03 DF 93 4F 4 F 0.0 09 **B**4 BB FF 18D0 B5 4F 4 F 0.0 4F B5 4 F 3D 18D8 FF 00 FF B 5 4F FF 00 00 F1 18E0 FF 00 FF 00 FF 00 FF 00 F4

PLUG.PLUG.PLUG

Merseyside

Group, some 150 strong, has put together a 64 page, **A4** book "Nascom Programs and entitled Information". The main part of book is the dedicated to the programs, some fifteen in a 1 1 including: 3D noughts and crosses Othello Income Tax Screenwriter Pico Pilot Crash Landing 2K Tiny Basic The INMC is able to offer these its for members 2.75 including postage and packing. Please note that the programs in this book are for use Nasbug T1, T2, T4 and B-Bug but not Nas-Sys. For use with Nas-Sys the various monitor calls require changing, other patching may be required.

Nascom

Users

```
10 REM
                *** HANGMAN ***
20 REM
30 REM By Howard Birkett, with minor assistance
40 REM from Paul Greenhalgh, and mods by Dave Hunt.
50 REM
50 REM For use with Nascom 1/2 using Nas-sys 1
70 REM monitors only.
80 REM
90 REM The vocabulary may be changed by
100 REM altering the DATA statements from line
110 REM 1010 onwards. The DATA statement at
120 REM line 1000 is the number of words in the
130 REM vocabulary.
140 REM
150 A$="ABCDEFGHIJKLMNOPQRSTUVWXYZ"
160 H$="HANGMAN"
170 DIM A(26), W(20):C=0:P=0
180 CLS:GOSUB 950:PRINT
190 INPUT "What is your name ";N$
200 RESTORE: READ I:DIM R(I)
210 FOR J=1 TO I:R(J)=0:NEXT
220 REM
230 REM ** Re-enter here
240 CLS:GOSUB 950 :W=0
250 SCREEN 1,2:PRINT N$" ="P;TAB(24) "Computer ="C
250 FOR I=1 TO 26:A(I)=0:NEXT
270 RESTORE 1000:READ R:R1=10*R
280 FOR I=1 TO R1:R9=INT(RND(1)*R+1)
290 IF R(R9)=0 THEN R(R9)=1:GOTO 310
300 NEXT:FOR I=1 TO R:R(I)=0:NEXT:GOTO 280
310 FOR I=1 TO R9:READ W$:NEXT
320 FOR I=1 TO LEN(W$):W(I)=0:NEXT
330 T=0
340 GOSUB 680:GOSUB 740
350 GOSUB 800
360 IF T=7 THEN 540
370 IF W=1 THEN 650
380 SCREEN 5,13:INPUT "What letter ";L$
390 REM
400 REM ** Check input validity
410 IF LEN(L$)=1ANDL$>="A"ANDL$<="Z" THEN 450
420 GOSUB 870:SCREEN 5,13
430 PRINT"One LETTER only will do !!"
440 GOSUB 900:GOSUB 870:GOTO 380
450 L=ASC(L$)-64:1F A(L)=0 THEN 480
450 GOSUB 870:SCREEN 5,13
470 PRINT "You've already tried "L$:GOTO 440
480 T1=0:A(L)=1:FOR I=1 TO LEN(W$)
490 IF L$=MID$(W$, 1, 1) THEN W(1)=1:T1=1
500 NEXT: GOSUB 870
510 IF T1=0 THEN T=T+1
520 FOR I=1 TO LEN(W$): IF W(I)=0 THEN 340
530 NEXT:W=1:GOTO 340
540 REM
```

550 REM ** Lose message

```
550 C=C+1
570 SCREEN 1,13
580 PRINT"Bad luck "N$" you lost.":PRINT 590 PRINT"The word was "W$".";
500 INPUT " Play again ";Q$
510 IF LEFT$ (Q$,1)="Y" THEN 220
620 CLS:GOSUB 350 :PRINT:PRINT "Goodbye "N$:END
630 REM
640 REM ** Win message
650 SCREEN 1,13
660 PRINT "Well done "N$", you won (this time !!)"
670 P=P+1:GOTO 500
680 REM
690 REM ** Print "II A N G M A N" message
700 SCREEN 18,4:FOR I=1 TO 7
710 IF T>=1 THEN PRINT MID$(H$, I, 1);" ";:GOTO 730
720 PRINT "* ";
730 NEXT:PRINT:RETURN
740 REM
750 REM ** Print the letters used
760 SCREEN 5,7:PRINT "Letters used: ";
770 FOR 1=0 TO 25:1F A(1)=0 THEN 790
780 PRINT MID$(A$,1,1);
790 NEXT:PRINT:RETURN
800 REM
810 REM ** Print the word so far
820 SCREEN 5,10:PRINT "Word is : ";
830 FOR I=1 TO LEN(W$)
840 IF W(1)=0 THEN PRINT "- ";:GOTO 860
850 PRINT MID$(W$,1,1);" ";
860 NEXT:PRINT:RETURN
870 REM
880 REM ** Clear input line
890 SCREEN 1,13:PRINT SPC(46):PRINT:RETURN
900 REM
910 REM ** Delay; change to 2000 for 4MHz
920 FOR Z=1 TO 1000:NEXT:RETURN
930 REM
940 REM ** Put up title
950 FOR I=1 TO LEN(H$)
960 POKE 3037+1,ASC(MID$(H$,1,1)):NEXT:RETURN
970 REM
980 REM ** Vocabulary
            Change line 1000 to number of words
930 REM
1000 DATA 49
1010 DATA KING, GARDEN, FRIEND, CASTLE, GARAGE
1020 DATA LAMPSHADE, FINGER, DRAWER, FIREPLACE
1030 DATA MACHINE, COMPUTER, RADIATOR, LEATHER
1040 DATA KETTLE, PICTURE, YACHT, HARBOUR
1050 DATA KITCHEN, ENGINE, TELEPHONE, SHOP
1050 DATA BICYCLE, ALBATROSS, GIRAFFE, TREE
1070 DATA NEWSPAPER, COOKER, SAUCEPAN, STREET
1080 DATA FLOWER, PENCIL, HANDBAG, DIARY, DAIRY
1030 DATA PARAPHERNALIA, DOG, MOUSE, ELEPHANT
1100 DATA FRUITCAKE, CASSETTE, CROQUET
1110 DATA TELEVISION, GUITAR, PIANO, ZEBRA
1120 DATA UMBRELLA, BIBLE, BANANA, HEDGEHOG
0 k
```

